

Using the TPS59650EVM-753 Intel™ IMVP-7 3-Phase CPU/2-Phase GPU SVID Power System

The TPS59650EVM-753 evaluation module (EVM) is a complete solution for Intel™ IMVP7 Serial VID(SVID) Power System from a 9V-20V input bus. This EVM uses the TPS59650 for IMVP7 - 3-Phase CPU and 2-Phase GPU Vcore controller, the TPS51219 for 1.05VCCIO, TPS51916 for DDR3L/DDR4 Memory rail (1.2VDDQ, 0.6VTT and 0.6VTTREF) and also uses the (CSD87350Q5D) a 5mm x 6mm TI's power block MOSFETs that uses Powerstack™ technology with high-side and low-side MOSFETs for high power density and superior thermal performance.

Contents

1	Description	5
	1.1 Typical Applications	5
	1.2 Features	5
2	TPS59650EVM-753 Power System Block Diagram	6
3	Electrical Performance Specifications	7
4	Test Setup	8
	4.1 Test Equipment	8
	4.2 Recommended Wire Gauge	9
	4.3 Recommended Test Setup	9
	4.4 USB Cable Connections	10
	4.5 Input Connections	10
	4.6 Output Connections	11
5	Configuration	11
	5.1 CPU and GPU Configuration	11
	5.2 1.2VDDQ, 0.6V VTT and 0.6V VTTREF Configuration	13
	5.3 1.05V VCCIO Configuration	13
6	Test Procedure	14
	6.1 Line/Load Regulation and Efficiency Measurement Procedure	14
	6.2 Equipment Shutdown	17
7	Performance Data and Typical Characteristic Curves	18
	7.1 CPU 3-Phase Operation	18
	7.2 CPU 2-Phase Operation	21
	7.3 CPU1-Phase Operation	25
	7.4 GPU 2 Phase Operation	29
	7.5 GPU 1 Phase Operation	32
	7.6 1.05V VCCIO	36
	7.7 1.2V VDDQ	39
8	EVM Assembly Drawings and PCB Layout	42
9	Bill of Materials	47
10	Schematics	50

List of Figures

1	TPS59650EVM-753 Power System Block Diagram	6
2	TPS59650EVM-753 EVM Illustration	7

Powerstack is a trademark of Texas Instruments.
 Intel is a trademark of Intel.
 All other trademarks are the property of their respective owners.

3	USB Cable	8
4	TPS59650EVM-753 Recommended Test Set Up.....	10
5	TPS59650EVM-753 CPU GUI set up Window	15
6	TPS59650EVM-753 GPU GUI set up Window	16
7	CPU3 Efficiency	18
8	CPU3 Load regulation	18
9	CPU3 Enable Turn on	18
10	CPU3 Enable Turn off	18
11	CPU3 Switching Node(Ripple)	18
12	CPU3 Dynamic VID: SetVID-Slow/Slow.....	18
13	CPU3 Dynamic VID:SetVID-Fast/Fast	19
14	CPU3 Dynamic VID:SetVID-Decay/Fast	19
15	CPU3 Output Load Insertion with OSR/USR middle level	19
16	CPU3 Output Load Release with OSR/USR middle level.....	19
17	CPU3 Bode Plot at 12Vin, 1.05V/60A	20
18	CPU3 MOSFET	20
19	CPU3 IC	20
20	CPU2 Efficiency	21
21	CPU2 Load regulation	21
22	CPU2 Enable Turn on	21
23	CPU2 Enable Turn off	21
24	CPU2 Switching Node(Ripple)	22
25	CPU2 Dynamic VID: SetVID-Slow/Slow.....	22
26	CPU2 Dynamic VID:SetVID-Fast/Fast	22
27	CPU2 Dynamic VID:SetVID-Decay/Fast	22
28	CPU2 Output Load Insertion with OSR/USR middle level	23
29	CPU2 Output Load Release with OSR/USR middle level.....	23
30	CPU2 Bode Plot at 12Vin, 1.05V/55A	24
31	CPU2 MOSFET	24
32	CPU2 IC	24
33	CPU1 Efficiency	25
34	CPU1 Load regulation	25
35	CPU1 Enable Turn on	25
36	CPU1 Enable Turn off	25
37	CPU1 Switching Node	25
38	CPU1 Switching node and Ripple	25
39	CPU1 Dynamic VID:SetVID-Slow/Slow	26
40	CPU1 Dynamic VID:SetVID-Fast/Fast	26
41	CPU1 Dynamic VID:SetVID-Decay/Fast	26
42	CPU1 Output Load Insertion with OSR/USR middle level	26
43	CPU1 Output Load Release with OSR/USR middle level.....	27
44	CPU1 Bode Plot at 12Vin, 1.05V/33A	28
45	CPU1 MOSFET	28
46	CPU1 IC	28
47	GPU2 Efficiency	29
48	GPU2 Load regulation	29
49	GPU2 Enable Turn on	29
50	GPU2 Enable Turn off	29
51	GPU2 Switching Node and Ripple	29

52	GPU2 Dynamic VID:SetVID-Slow/Slow	29
53	GPU2 Dynamic VID:SetVID-Fast/Fast	30
54	GPU2 Dynamic VID:SetVID-Decay/Fast	30
55	GPU2 Output Load Insertion with OSR/USR OFF	30
56	GPU2 Output Load Release with OSR/USR OFF	30
57	GPU2 Bode Plot at 12Vin, 1.23V/50A	31
58	GPU2 MOSFET	31
59	GPU2 IC	31
60	GPU1 Efficiency	32
61	GPU1 Load regulation	32
62	GPU1 Enable Turn on	32
63	GPU1 Enable Turn off	32
64	GPU1 Switching Node	33
65	GPU1 Switching Node and Ripple	33
66	GPU1 Dynamic VID:SetVID-Slow/Slow	33
67	GPU1 Dynamic VID:SetVID-Fast/Fast	33
68	GPU1 Dynamic VID:SetVID-Decay/Fast	34
69	GPU1 Output Load Insertion with OSR/USR OFF	34
70	GPU1 Output Load Release with OSR/USR OFF	34
71	GPU1 Bode Plot at 12Vin, 1.23V/33A	35
72	GPU1 MOSFET	35
73	GPU1 IC	35
74	1.05V Efficiency	36
75	1.05V Load regulation	36
76	1.05V Enable Turn on	36
77	1.05V Enable Turn off	36
78	1.05V Switching Node	37
79	1.05V Ripple	37
80	1.05V Transient DCM TO CCM	37
81	1.05V Transient CCM to DCM	37
82	TPS51219 Thermal.....	38
83	1.2V Efficiency	39
84	1.2V Load regulation	39
85	1.2V Enable Turn on	39
86	1.2V Enable Turn off	39
87	1.2V Switching Node	39
88	1.2V Ripple	39
89	1.2V Transient DCM TO CCM	40
90	1.2V Transient CCM to DCM	40
91	TPS51916 Thermal.....	41
92	TPS59650EVM-753 Top Layer Assembly Drawing (Top view)	42
93	TPS59650EVM-753 Bottom Assembly Drawing (Bottom view)	42
94	TPS59650EVM-753 Top Copper	43
95	TPS59650EVM-753 Bottom Copper	43
96	TPS59650EVM-753 Internal Layer 2	44
97	TPS59650EVM-753 Internal Layer 3	44
98	TPS59650EVM-753 Internal Layer 4	45
99	TPS59650EVM-753 Internal Layer 5	45

100	TPS59650EVM-753 Internal Layer 6	46
101	TPS59650EVM-753 Internal Layer 7	46

List of Tables

1	TPS59650EVM-753 Electrical Performance Specifications	7
2	Current Limit Trip Selection	11
3	CPU Frequency Selection	11
4	GPU Frequency Selection	12
5	F2808 DSP Program Mode Selection	12
6	5Vin Bias Voltage Option (J33)	12
7	On Board Dynamic Load Selection	12
8	VR_ON Enable Selection	13
9	VDDQ S3, S5 Enable Selection	13
10	1.05V Enable Selection	13
11	VCCIO Output Voltage Selection	13
12	On Board Dynamic Load Enable/Disable selection	14
13	EVM Major Components List	47

1 Description

The TPS59650EVM-753 is designed to use a 9V-20V Input bus to produce 6 regulated outputs for IMVP7 SVID CPU/GPU Power System. The TPS59650EVM-753 is specially designed to demonstrate the TPS59650 full IMVP7 mobile feature while providing GUI communication programming and a number of test points to evaluate the static and dynamic performance of TPS59650.

1.1 Typical Applications

- IMVP7 Vcore Applications for Adapter, Battery, NVDC or 3V/5V/12V rails

1.2 Features

The TPS59650EVM-753 features:

- Complete solution for 9V-20V Input Intel IMVP7 SVID Power System
- GUI communication to demonstrate full IMVP7 Mobile feature
- 3-Phase CPU Vcore can support up to 94A output current
- 2-Phase GPU Vcore can support up to 46A output current
- 8 Selectable Switching frequency for CPU and GPU power
- 8 Levels selectable current limit for CPU and GPU power
- Switches or Jumpers for each output enable
- On Board Dynamic Load for CPU, GPU Vcore and VCCIO output
- High efficiency and high density by using TI power block MOSFET
- Convenient test points for probing critical waveforms
- Eight Layer PCB with 1oz copper

2 TPS59650EVM-753 Power System Block Diagram




Figure 1. TPS59650EVM-753 Power System Block Diagram




Figure 2. TPS59650EVM-753 EVM Illustration

3 Electrical Performance Specifications

Table 1. TPS59650EVM-753 Electrical Performance Specifications⁽¹⁾

PARAMETER	TEST CONDITIONS	MIN	TYP	MAX	UNITS
INPUT CHARACTERISTICS					
12VBAT input voltage range	VBAT	9	12	20	V
Maximum input current	VBAT = 12V, all full load (3-Phase CPU/2-Phase GPU)		15.5		A
No load input current	VBAT=12V, all no load(3-Phase CPU/2 Phase GPU)		0.14		A
5VIN input voltage range	5Vin	4.5	5	5.5	V
Maximum input current	VBAT =12 V, all full load		0.3		A
No load input current	VBAT=12V, all no load		0.1		A
OUTPUT CHARACTERISTICS					
CPU(TPS59650)					
Output voltage Vcore	SVID: Address:00 CPU, Payload: 1.05V		1.05		V
Output voltage regulation	Line regulation		0.1%		
	Load regulation(Droop) Load Line		-1.9		mΩ
Output voltage ripple	VBAT=12V, 1.05V/90A(3-Phase) at 300kHz		25		mVpp
Output load current	CPU 3-Phase operation	0		94	A
Output over current	Selectable per phase		37		A
Switching frequency	Selectable	250	300	600	kHz
Full load efficiency	VBAT=12V, 1.05V/95A at 300kHz		80.05%		
GPU(TPS59650)					
Output voltage Vcore	SVID: Address:01 GPU, Payload: 1.23V		1.23		V

⁽¹⁾ Jumpers set to default locations, see section 6 of this user's guide

Table 1. TPS59650EVM-753 Electrical Performance Specifications⁽¹⁾ (continued)

PARAMETER	TEST CONDITIONS	MIN	TYP	MAX	UNITS
Output voltage regulation	Line regulation		0.1%		
	Load regulation(Droop) Load Line		-3.9		mΩ
Output voltage ripple	VBAT=12V, 1.23V/50A 2 Phase at 385kHz		30		mVpp
Output load current		0		50	A
Output over current	Selectable per phase		37		A
Switching frequency	Selectable	275	385	660	kHz
Full load efficiency	VBAT=12V, 1.23V/50A 2 Phase at 385kHz		86.58%		
1.05V VCCIO (TPS51219)					
Output voltage			1.05		V
Output voltage regulation	Line regulation		0.1%		
	Load regulation		0.1%		
Output voltage ripple	VBAT=12V, 1.05V/10A		30		mVpp
Output load current		0		10	A
Output over current			16		A
Switching frequency	Selectable		500		kHz
Full load efficiency	VBAT=12V, 1.05V/10A		89.87%		
DDR3L/DDR4 Memory Rail (TPS51916)					
Output voltage			1.2		V
Output voltage regulation	Line regulation		0.1%		
	Load regulation		0.1%		
Output voltage ripple	VBAT=12V, 1.2V/8A		30		mVpp
Output load current		0		8	A
Output over current			10		A
Switching frequency	Selectable		500		kHz
Full load efficiency	VBAT=12V, 1.2V/8A		89.07%		
Operating temperature			25		°C

4 Test Setup

4.1 Test Equipment

4.1.1 PC Computer (Host Computer)

Microsoft Windows XP or newer with available USB port

4.1.2 USB Cable

The USB Cable: Standard USB_A to USB_B 5 Pin Mini-B cable. See [Figure 3](#) .



Figure 3. USB Cable

4.1.3 TPS59650 USB driver and SVID GUI Installation

1. Copy the both files: setup.exe and setup.msi to the host computer.
2. Run this setup.exe.
3. Following installation Instructions, this will install the driver and the Texas Instruments SVID GUI.
4. It will add the below icon



4.1.4 DC Source

12VBAT DC Source: The 12VBAT DC source should be a 0-20V variable DC source capable of supplying 20Adc current. Connect 12VBAT to J21 as shown in [Figure 4](#).

5Vin DC Source: The 5Vin DC source should be a 0-5V variable DC source capable of supplying 1Adc current. Connect 5Vin to J22 as shown in [Figure 4](#).

4.1.5 Meters

- **V1:** 5Vin at TP81(5Vin) and TP83(GND)
- **V2:** 12VBAT at TP82(VBAT) and TP24(GND)
- **V3:** CPU Vcore sense voltage at J7; GPU Vcore sense voltage at J9; VDDQ sense voltage at J20, VCCIO sense voltage at J16
- **A1:** 12VBAT input current

4.1.6 Load

The output load should be an electronic constant current load capable of 0-90Adc.

4.1.7 Oscilloscope

A digital or analog oscilloscope can be used to measure the output ripple. The oscilloscope should be set for 1M Ω impedance, 20MHz Bandwidth, AC coupling, 2us/division horizontal resolution, 50mV/division vertical resolution. Test point TP30 and TP46 can be used to measure the output ripple voltage for CPU and GPU. Do not use a leaded ground connection as this may induce additional noise due to the large ground loop.

4.2 Recommended Wire Gauge

1. **V5in to J22(5V input):**
The recommended wire size is 1x AWG #18 per input connection, with the total length of wire less than 4 feet (2 feet input, 2 feet return).
2. **12VBAT to J21(12V input):**
The recommended wire size is 1x AWG #16 per input connection, with the total length of wire less than 4 feet (2 feet input, 2 feet return).
3. **J1, J2, J3(CPU) to LOAD or J4, J5 (GPU) to LOAD or J19 (VDDQ) to LOAD or J15(VCCIO) to LOAD:**
The minimum recommended wire size is 2x AWG #16, with the total length of wire less than 4 feet (2 feet output, 2 feet return)

4.3 Recommended Test Setup

[Figure 4](#) is the recommended test set up to evaluate the TPS59650EVM-753. Working at an ESD workstation, make sure that any wrist straps, bootstraps or mats are connected referencing the user to earth ground before handling the EVM.




Figure 4. TPS59650EVM-753 Recommended Test Set Up

4.4 USB Cable Connections

A standard USB_A and 5 pin Mini_B USB cable needed to connect between host computer and J34 USB port (left bottom side). A GREEN LED(D13) will light up near the USB port on the EVM. This just means USB cable is connected.

4.5 Input Connections

1. Prior to connecting the 5Vin DC source, it is advisable to limit the source current from 5Vin to 1A maximum. Make sure 5Vin is initially set to 0V and connected as shown in [Figure 4](#).
2. Prior to connecting the 12VBAT DC source, it is advisable to limit the source current from 12VBAT to 10A maximum. Make sure 12VBAT is initially set to 0V and connected as shown in [Figure 4](#).
3. Connect voltmeters V1 at TP81 (5Vin) and TP83 (GND) to measure 5Vin voltage, V2 at TP82 (VBAT) and TP24 (GND) to measure 12VBAT voltage as shown in [Figure 4](#).
4. Connect a current meter A1 between 12VBAT DC source and J21 to measure the 12VBAT input current.

4.6 Output Connections

1. Connect Load to J1, J2, J3 and set Load to constant resistance mode to sink 0Adc before 5Vin and 12VBAT are applied. This is for CPU operation.
2. Connect a voltmeter V3 at J7 to measure CPU Vcore sense voltage.

5 Configuration

All Jumper selections should be made prior to applying power to the EVM. User can configure this EVM per following configurations.

5.1 CPU and GPU Configuration

5.1.1 CPU/GPU Current Limit Trip Selection (J10 for CPU and J12 for GPU)

The current limit trip can be set by J10(COCP) and J12(GOCP).

Default setting: Level 5 for both CPU and GPU.

Table 2. Current Limit Trip Selection

Jumper set to	Connected Resistor	COCP/GOCP Limit (Typ.)
Left (1-2 pin shorted)	150k	Max
2 nd (3-4 pin shorted)	100k	Level 7
3 rd (5-6 pin shorted)	75k	Level 6
4th(7-8 pin shorted)	56.2k	Level 5
5 th (9-10 pin shorted)	39.2k	Level 4
6 th (11-12 pin shorted)	30.1k	Level 3
7 th (13-14 pin shorted)	24.3k	Level 2
Right(15-16 pin shorted)	20.0k	Min

5.1.2 CPU Frequency Selection (J11)

The operating frequency can be set by J11

Default setting: 300 kHz for CPU

Table 3. CPU Frequency Selection

Jumper set to	Connected Resistor	CPU
Left (1-2 pin shorted)	150k	600 kHz
2 nd (3-4 pin shorted)	100k	550 kHz
3 rd (5-6 pin shorted)	75k	500 kHz
4 th (7-8 pin shorted)	56.2k	450 kHz
5 th (9-10 pin shorted)	39.2k	400 kHz
6 th (11-12 pin shorted)	30.1k	350 kHz
7th(13-14 pin shorted)	24.3k	300 kHz
Right(15-16 pin shorted)	20.0k	250 kHz

5.1.3 GPU Frequency Selection (J13)

The operating frequency can be set by J13

Default setting: 385 kHz for GPU.

Table 4. GPU Frequency Selection

Jumper set to	Connected Resistor	GPU
Left (1-2 pin shorted)	150k	660 kHz
2 nd (3-4 pin shorted)	100k	605 kHz
3 rd (5-6 pin shorted)	75k	550 kHz
4 th (7-8 pin shorted)	56.2k	495 kHz
5 th (9-10 pin shorted)	39.2k	440 kHz
6th(11-12 pin shorted)	30.1k	385 kHz
7 th (13-14 pin shorted)	24.3k	330 kHz
Right(15-16 pin shorted)	20.0k	275 kHz

5.1.4 F2808 DSP Program Mode Selection (J39)

The F2808 DSP Program Mode(GUI) Selection can be set by J39.

Default setting: No Jumper shorts on J39 for normal operation

Table 5. F2808 DSP Program Mode Selection

Jumper set to	Program Mode Selection
No Jumper on J39	Normal Operation
Jumper on J39	Flash the DSP program to the EVM

5.1.5 5Vin Bias Voltage Option (J33)

The 5Vin Bias Voltage can be used from USB or Externally

Default setting: No Jumper shorts on J33

Table 6. 5Vin Bias Voltage Option (J33)

Jumper set to	Selection
No Jumper	5Vin Bias from J22 external
Jumper on J39	5Vin Bias from USB, 5Vin from J22 should not be connected

5.1.6 On Board Dynamic Load Selection (S3 for CPU, S2(upper) for GPU, S2(lower) for VCCIO)

The on board dynamic load can be set by S2 and S3.

Default setting: Push S2 and S3 to “OFF” position to disable the on board dynamic load

Table 7. On Board Dynamic Load Selection

Switch set to	Dynamic Load Selection
Push S3 to “ON” position	Enable 32A on board dynamic load at CPU
Push S3 to “OFF” position	Disable 32A on board dynamic load at CPU
Push S2(upper) to “ON” position	Enable 19A on board dynamic load at GPU
Push S2(upper) to “OFF” position	Disable 19A on board dynamic load at GPU
Push S2(lower) to “ON” position	Enable 10A on board dynamic load at VCCIO
Push S2(lower) to “OFF” position	Disable 10A on board dynamic load at VCCIO

5.1.7 IMVP-7 VR_ON Enable Selection (S4)

The IMVP-7 CPU/GPU can be enabled and disabled by S4

Default setting: Push S4 to “OFF” position to disable both CPU and GPU

Table 8. VR_ON Enable Selection

Switch set to	VR_ON Selection
Push S4 to “ON” position	Enable IMVP-7 CPU/GPU Vcore
Push S4 to “OFF” position	Disable IMVP-7 CPU/GPU Vcore

5.2 1.2VDDQ, 0.6V VTT and 0.6V VTTREF Configuration

5.2.1 VDDQ S3, S5 Enable Selection

The controller can be enabled and disabled by J18 and J17.

**Default setting: Jumper shorts on Pin2 and Pin3 of J18,
Jumper shorts on Pin2 and Pin3 of J17**

Table 9. VDDQ S3, S5 Enable Selection

State	J17 (S3) set to	J18(S5) set to	VDDQ	VTTREF	VTT
S0	ON position	ON position	ON	ON	ON
S3	OFF position	ON position	ON	ON	OFF(High-Z)
S4/S5	OFF position	OFF position	OFF(Discharge)	OFF(Discharge)	OFF(Discharge)

5.3 1.05V VCCIO Configuration

5.3.1 1.05V Enable Selection (S1)

1.05V Enable can be set by S1

Default setting: Push S1 to “OFF” position

Table 10. 1.05V Enable Selection

Jumper set to	Selection
Push S1 to “ON” position	1.05V Enabled
Push S1 to “OFF” position	1.05V Disabled

5.3.2 VCCIO Output Voltage Selection (J14)

The VCCIO Output Voltage can be selected by J14

Default setting: Jumper shorts Pin1 and Pin2 of J14

Table 11. VCCIO Output Voltage Selection

Jumper set to	Selection
Jumper shorts on Pin1 and Pin2	VCCIO: 1.05V
Jumper shorts on Pin2 and Pin3	VCCIO: 1.00V

5.3.3 On Board Dynamic Load Enable Pin (J23)

The on board dynamic load can be enabled or disabled by J23

Default setting: Jumper shorts on J23

Table 12. On Board Dynamic Load Enable/Disable selection

Jumper set to	Selection
Jumper shorts	Enable on board dynamic load
No Jumper short	Disable on board dynamic load

6 Test Procedure

6.1 Line/Load Regulation and Efficiency Measurement Procedure

6.1.1 CPU

1. Set up EVM as described in [Section 4.3](#) through [Section 4.6](#) and [Figure 4](#).
2. Ensure J39 no Jumper shorts on
3. Ensure all other Jumpers configuration setting by [Section 5](#) before 5V_{in} and 12VBAT are applied.
4. Ensure Load is set to constant resistance mode and to sink 0Adc
5. Ensure S1 and S4 are in “OFF” position
6. Add scope probe on the TP30 for CPU Vcore ripple measurement
7. Ensure USB Cable is connected between host computer and USB port(J34) on the EVM
8. Increase 5V_{in} from 0V to 5V. Using V1 to measure 5V_{in} input voltage.
9. Increase 12VBAT from 0V to 12V. Using V2 to measure 12VBAT input voltage.



10. Double-Click the icon to launch the GUI program. The GUI window shown in [Figure 5](#).
11. Push S4 to “ON” position to enable the VR_ON of TPS59650. VR_ON LED will light up.
12. Now the user is ready to send SVID commends. The GUI at start-up defaults:
Address: 00 CPU, Command: SetVIDslow, Payload: 1.05V (The user can select the SVID command by using the pull-down menu”)
13. Click “send Command” and CPU CPGOOD LED will light up, See the GUI window as [Figure 5](#).
14. Measure V3: CPU Vcore at J7 and A1: 12VBAT input current
15. Vary CPU LOAD from 0Adc to 94Adc, CPU Vcore must remain in load line
16. Vary 12VBAT from 9V to 20V CPU Vcore must remain in line regulation
17. Push S4 to “OFF” position to disable CPU Vcore controller.
18. Decrease LOAD to 0A and disconnect the LOAD from terminal J1, J2, J3
19. Disconnect V3 from J7.
20. Disconnect scope probe from TP30




Figure 5. TPS59650EVM-753 CPU GUI set up Window

6.1.2 GPU

1. Connect the LOAD to GPU terminal J4, J5 and V3 at J9. Ensure correct polarity.
2. Add scope probe on the TP46 for GPU Vcore_G ripple measurement
3. Push S4 to "ON" position to enable the VR_ON of TPS59650. The VR_ON LED will light up.
4. Now you are ready to send SVID commands for GPU. Using pull-down menu:
Address: **01 GPU**, Command: SetVIDslow, Payload: **1.23V**
5. Click "send Command" and GPU GPOOD LED will light up, See the GUI window as [Figure 6](#).




Figure 6. TPS59650EVM-753 GPU GUI set up Window

6. Measure V3: GPU Vcore_G at J9 and A1: 12VBAT input current
7. Vary GPU LOAD from 0Adc to 50Adc, GPU Vcore must remain in load line
8. Vary 12VBAT from 9V to 20V GPU Vcore must remain in line regulation
9. Push S4 to "OFF" position to disable GPU Vcore controller.
10. Decrease LOAD to 0A and disconnect the LOAD from terminal J11
11. Disconnect V3 from J9.
12. Disconnect scope probe from TP46
13. Exit SVID GUI window: click File → click Exit
14. Disconnect the USB cable between host Computer and EVM

6.1.3 VDDQ

1. Connect the LOAD to VDDQ terminal J19 and V3 at J20. Ensure correct polarity.
2. Remove Jumper from J17, J18 from pin2 and pin3 and put this Jumper on pin1 and pin 2 of J18, J17 to enable S5 of VDDQ controller. VDDQ PGOOD LED will light up.
3. Measure V3: VDDQ at J20 and A1: 12Vin input current
4. Vary VDDQ LOAD from 0Adc to 8Adc, VDDQ must remain in the load regulation
5. Vary 12VBAT from 9V to 20V, VDDQ must remain in the line regulation
6. Remove Jumper of J17, J18 and shorts back on pin2 and pin3 of J17, J18 to disable VDDQ controller.
7. Decrease LOAD to 0A and disconnect the LOAD from terminal J19
8. Disconnect V3 from J20.

6.1.4 VCCIO

1. Connect the LOAD to VCCIO terminal J15 and V3 at J16. Ensure correct polarity.
2. Push S1 to "ON" position to enable the VCCIO controller. VCCIO EN and PGOOD LED will light up.
3. Measure V3: VCCIO at J16 and A1: 12Vin input current
4. Vary VDDQ LOAD from 0Adc to 10Adc, VCCIO must remain in the load regulation
5. Vary 12VBAT from 9V to 20V, VCCIO must remain in the line regulation
6. Push S1 to "OFF" position to disable VCCIO controller.
7. Decrease LOAD to 0A and disconnect the LOAD from terminal J15
8. Disconnect V3 from J16.

6.2 Equipment Shutdown

1. Shut down Load
2. Shut down 12VBAT and 5Vin
3. Shut down oscilloscope
4. Shut down host computer

7 Performance Data and Typical Characteristic Curves

Figure 7 through Figure 91 present typical performance curves for TPS59650EVM-753. Jumpers set to default locations, see section 6 of this user's guide.

7.1 CPU 3-Phase Operation




Figure 7. CPU3 Efficiency




Figure 8. CPU3 Load regulation




Figure 9. CPU3 Enable Turn on




Figure 10. CPU3 Enable Turn off




Figure 11. CPU3 Switching Node(Ripple)




Figure 12. CPU3 Dynamic VID: SetVID-Slow/Slow




Figure 13. CPU3 Dynamic VID:SetVID-Fast/Fast




Figure 14. CPU3 Dynamic VID:SetVID-Decay/Fast




Figure 15. CPU3 Output Load Insertion with OSR/USR middle level




Figure 16. CPU3 Output Load Release with OSR/USR middle level




Figure 17. CPU3 Bode Plot at 12Vin, 1.05V/60A

Test condition: CPU3 12Vin, 1.05V/60A no airflow




Figure 18. CPU3 MOSFET




Figure 19. CPU3 IC

7.2 CPU 2-Phase Operation




Figure 20. CPU2 Efficiency




Figure 21. CPU2 Load regulation




Figure 22. CPU2 Enable Turn on




Figure 23. CPU2 Enable Turn off




Figure 24. CPU2 Switching Node(Ripple)




Figure 25. CPU2 Dynamic VID: SetVID-Slow/Slow




Figure 26. CPU2 Dynamic VID: SetVID-Fast/Fast




Figure 27. CPU2 Dynamic VID: SetVID-Decay/Fast




Figure 28. CPU2 Output Load Insertion with OSR/USR middle level




Figure 29. CPU2 Output Load Release with OSR/USR middle level




Figure 30. CPU2 Bode Plot at 12Vin, 1.05V/55A

Test condition: CPU2 12Vin, 1.05V/55A no airflow




Figure 31. CPU2 MOSFET




Figure 32. CPU2 IC

7.3 CPU1-Phase Operation




Figure 33. CPU1 Efficiency




Figure 34. CPU1 Load regulation




Figure 35. CPU1 Enable Turn on




Figure 36. CPU1 Enable Turn off




Figure 37. CPU1 Switching Node




Figure 38. CPU1 Switching node and Ripple




Figure 39. CPU1 Dynamic VID: SetVID-Slow/Slow




Figure 40. CPU1 Dynamic VID: SetVID-Fast/Fast




Figure 41. CPU1 Dynamic VID: SetVID-Decay/Fast




Figure 42. CPU1 Output Load Insertion with OSR/USR middle level




Figure 43. CPU1 Output Load Release with OSR/USR middle level




Figure 44. CPU1 Bode Plot at 12Vin, 1.05V/33A

Test condition: CPU1 12Vin, 1.05V/33A no airflow




Figure 45. CPU1 MOSFET




Figure 46. CPU1 IC

7.4 GPU 2 Phase Operation




Figure 47. GPU2 Efficiency




Figure 48. GPU2 Load regulation




Figure 49. GPU2 Enable Turn on




Figure 50. GPU2 Enable Turn off




Figure 51. GPU2 Switching Node and Ripple




Figure 52. GPU2 Dynamic VID: SetVID-Slow/Slow




Figure 53. GPU2 Dynamic VID: SetVID-Fast/Fast




Figure 54. GPU2 Dynamic VID: SetVID-Decay/Fast




Figure 55. GPU2 Output Load Insertion with OSR/USR OFF




Figure 56. GPU2 Output Load Release with OSR/USR OFF




Figure 57. GPU2 Bode Plot at 12Vin, 1.23V/50A

Test condition: GPU2 12Vin, 1.23V/50A no airflow




Figure 58. GPU2 MOSFET




Figure 59. GPU2 IC

7.5 GPU 1 Phase Operation




Figure 60. GPU1 Efficiency




Figure 61. GPU1 Load regulation




Figure 62. GPU1 Enable Turn on




Figure 63. GPU1 Enable Turn off




Figure 64. GPU1 Switching Node




Figure 65. GPU1 Switching Node and Ripple




Figure 66. GPU1 Dynamic VID:SetVID-Slow/Slow




Figure 67. GPU1 Dynamic VID:SetVID-Fast/Fast




Figure 68. GPU1 Dynamic VID:SetVID-Decay/Fast




Figure 69. GPU1 Output Load Insertion with OSR/USR OFF




Figure 70. GPU1 Output Load Release with OSR/USR OFF




Figure 71. GPU1 Bode Plot at 12Vin, 1.23V/33A

Test condition: GPU1 12Vin, 1.23V/33A no airflow




Figure 72. GPU1 MOSFET




Figure 73. GPU1 IC

7.6 1.05V VCCIO




Figure 74. 1.05V Efficiency




Figure 75. 1.05V Load regulation




Figure 76. 1.05V Enable Turn on




Figure 77. 1.05V Enable Turn off




Figure 78. 1.05V Switching Node




Figure 79. 1.05V Ripple




Figure 80. 1.05V Transient DCM TO CCM

Test condition: 12Vin, 1.05V/10A no airflow




Figure 81. 1.05V Transient CCM to DCM




Figure 82. TPS51219 Thermal

7.7 1.2V VDDQ




Figure 83. 1.2V Efficiency




Figure 84. 1.2V Load regulation




Figure 85. 1.2V Enable Turn on




Figure 86. 1.2V Enable Turn off




Figure 87. 1.2V Switching Node




Figure 88. 1.2V Ripple




Figure 89. 1.2V Transient DCM TO CCM

Test condition: 12Vin, 1.2V/7.5A no airflow




Figure 90. 1.2V Transient CCM to DCM




Figure 91. TPS51916 Thermal




Figure 94. TPS59650EVM-753 Top Copper




Figure 95. TPS59650EVM-753 Bottom Copper




Figure 96. TPS59650EVM-753 Internal Layer 2




Figure 97. TPS59650EVM-753 Internal Layer 3




Figure 98. TPS59650EVM-753 Internal Layer 4




Figure 99. TPS59650EVM-753 Internal Layer 5




Figure 100. TPS59650EVM-753 Internal Layer 6




Figure 101. TPS59650EVM-753 Internal Layer 7

9 Bill of Materials

The EVM major components list according to the schematic shown in the following pages.

Table 13. EVM Major Components List

QTY	REF DES	Description	MFR	Part Number
11	C1, C12, C31, C69, C74, C124, C159, C121, C130, C184, C204	Capacitor, Ceramic, 1nF, 50V, X7R, 10%, 0603	STD	STD
5	C104, C108, C112, C115, C118	Capacitor, Ceramic, 33nF, 25V, X7R, 10%, 0603	STD	STD
29	C128, C164, C198, C199, C201, C127, C172, C188, C192, C203, C207, C190, C209, C210, C216, C217, C218, C219, C220, C221, C222, C223, C224, C225, C226, C227, C228, C229, C230	Capacitor, Ceramic, 0.1uF, 25V, X7R, 10%, 0603	STD	STD
3	C129, C133, C168	Capacitor, Polymer, 330uF, 2V, 6mohm, 20%, 7343	Sanyo	2TPF330M6
2	C13, C26	Capacitor, Ceramic, 100pF, 50V, C0G, 10%, 0603	STD	STD
3	C131, C239, C246	Capacitor, Ceramic, 10nF, 50V, X7R, 10%, 0603	STD	STD
6	C15, C16, C19, C20, C76, C77	Capacitor, Polymer, 470uF, 2V, 4mohm, 20%, D2T	Sanyo	2TPLF470M4E
1	C166	Capacitor, Ceramic, 2.2uF, 6.3V, X5R, 10%, 0805	STD	STD
1	C17	Capacitor, Ceramic, 0.33uF, 6.3V, X7R, 10%, 0603	STD	STD
1	C171	Capacitor, Ceramic, 0.22uF, 50V, X7R, 10%, 0603	STD	STD
15	C18, C23, C33, C75, C80, C196, C202, C208, C195, C200, C242, C250, C22, C233, C234	Capacitor, Ceramic, 1uF, 25V, X7R, 10%, 0603	STD	STD
7	C193, C36, C79, C82, C7, C135, C170	Capacitor, Ceramic, 2.2uF, 6.3V, X5R, 10%, 0603	STD	STD
3	C194, C197, C215	Capacitor, Ceramic, 0.01uF, 50V, X7R, 10%, 0603	STD	STD
28	C2, C3, C4, C5, C8, C9, C10, C11, C27, C28, C29, C30, C65, C66, C67, C68, C70, C71, C72, C73, C122, C123, C125, C126, C160, C161, C162, C163	Capacitor, Ceramic, 10uF, 25V, X7R, 20%, 1206	STD	STD
2	C205, C206	Capacitor, Ceramic, 10pF, 50V, C0G, 10%, 0603	STD	STD
2	C213, C214	Capacitor, Ceramic, 22pF, 50V, C0G, 10%, 0603	STD	STD
2	C240, C248	Capacitor, Ceramic, 0.22uF, 25V, X7R, 10%, 0402	STD	STD
2	C241, C249	Capacitor, Ceramic, 220pF, 25V, X7R, 10%, 0402	STD	STD
2	C243, C251	Capacitor, Ceramic, 680pF, 25V, X7R, 10%, 0402	STD	STD
2	C244, C252	Capacitor, Ceramic, 100pF, 25V, C0G, 10%, 0402	STD	STD
2	C245, C253	Capacitor, Ceramic, 1.8nF, 25V, X7R, 10%, 0402	STD	STD
2	C247, C254	Capacitor, Ceramic, 2200pF, 25V, X7R, 10%, 0402	STD	STD
44	C37, C38, C39, C40, C41, C42, C43, C45, C49, C50, C51, C52, C53, C54, C55, C56, C87, C88, C89, C90, C91, C92, C93, C94, C95, C100, C101, C102, C136, C140, C141, C143, C145, C146, C147, C148, C150, C151, C152, C154, C235, C236, C237, C238	Capacitor, Ceramic, 22uF, 6.3V, X5R, 10%, 0805	STD	STD
20	C44, C46, C57, C58, C59, C60, C61, C62, C63, C64, C173, C174, C175, C176, C180, C182, C165, C185, C189, C191	Capacitor, Ceramic, 10uF, 6.3V, X5R, 10%, 0805	STD	STD
1	C6	Capacitor, Ceramic, 4.7uF, 6.3V, X5R, 10%, 0805	STD	STD
8	D1, D2, D3, D9, D10, D12, D13, D14	Diode, LED, Green Clear, 20mcd, 0.079x0.049	Lite On	LTST-C170GKT

Table 13. EVM Major Components List (continued)

QTY	REF DES	Description	MFR	Part Number
5	D4, D5, D7, D8, D11	Diode, LED, Red Clear, 20mcd, 0.079x0.049	Lite On	LTST-C170CKT
1	D6	Diode, Schottky, 200mA, 30V, SOT-23,	Vishay-Liteon	BAT54-V-GS08
1	FB1	Bead, SMD,Ferrite, 100MHz Max, 200mA, +/-25%, 0603	WE	74279266A
5	L1, L2, L3, L4, L5	Inductor, SMT, 0.36uH, 35A , 0.82mohm, 10x11.5mm	Toko	FCUL1040-H-R36M
1	L6	Inductor, SMT, 0.42uH, 17A , 1.5mohm, 8.7x7.0mm	Panasonic	ETQP4LR42AFM
1	L7	Inductor, SMT, 1.0uH, 8.1A , 6.9mohm, 7.3x6.6mm	Panasonic	ETQP3W1R0WFN
7	Q1, Q2, Q3, Q4, Q5, Q8, Q10	MOSFET, Synchronous Buck NexFET Power Block SON 5X6mm	TI	CSD87350Q5D
4	Q11, Q12, Q13, Q14	MOSFET, Nchan, 25V, 31A, 2.5mohm, QFN5X6mm	TI	CSD16407Q5
1	Q15	MOSFET, Pchan, -60V, -0.33A, 2ohm, SOT23	Infineon	BSS83P
6	Q6, Q7, Q9, Q16, Q17, Q18	MOSFET, Nchan, 100V, 0.17A, 6ohm, SOT23	Fairchild	BSS123
1	R1	Resistor, Chip, 42.2k, 1/10W, 1%, 0603	STD	STD
4	R101, R102, R118, R119	Resistor, Chip, 56.2k, 1/10W, 1%, 0603	STD	STD
1	R104	Resistor, Chip, 2.43k, 1/10W, 1%, 0603	STD	STD
7	R106, R107, R122, R123, R141, R165, R166	Resistor, Chip, 30.1k, 1/10W, 1%, 0603	STD	STD
4	R108, R109, R124, R125	Resistor, Chip, 24.3k, 1/10W, 1%, 0603	STD	STD
22	R12, R15, R24, R31, R36, R41, R54, R58, R73, R76, R140, R142, R144, R145, R156, R157, R159, R161, R232, R233, R250, R268	Resistor, Chip, 0, 1/10W, 1%, 0603	STD	STD
7	R130, R131, R147, R215, R216, R217, R222	Resistor, Chip, 180, 1/10W, 1%, 0603	STD	STD
14	R132, R148, R149, R150, R158, R183, R185, R205, R214, R219, R220, R221, R230, R231	Resistor, Chip, 10.0k, 1/10W, 1%, 0603	STD	STD
5	R133, R134, R151, R213, R218	Resistor, Chip, 1.00k, 1/10W, 1%, 0603	STD	STD
1	R139	Resistor, Chip, 10.5k, 1/10W, 1%, 0603	STD	STD
1	R152	Resistor, Chip, 22.1k, 1/10W, 1%, 0603	STD	STD
6	R16, R110, R111, R126, R127, R160	Resistor, Chip, 20.0k, 1/10W, 1%, 0603	STD	STD
1	R163	Resistor, Chip, 15.0k, 1/10W, 1%, 0603	STD	STD
4	R164, R237, R238, R239	Resistor, Chip, 2.00k, 1/10W, 1%, 0603	STD	STD
1	R167	Resistor, Chip, 51.1k, 1/10W, 1%, 0603	STD	STD
1	R168	Resistor, Chip, 1, 1/10W, 1%, 0603	STD	STD
1	R176	Resistor, Chip Array, 10.0k, 62.5mW, 5%, 1206	Yageo	TC164-JR-0710KL
3	R169, R170, R171	Resistor, Chip, 1, 1/8W, 1%, 0805	STD	STD
3	R172, R173, R178	Resistor, Chip, 0.01, 1W, 1%, 2512	STD	STD
5	R174, R175, R177, R179, R180	Resistor, Chip, 0.05, 1W, 1%, 2512	STD	STD
5	R176, R177, R178, R179, R199	Resistor, Chip, 330, 1/10W, 1%, 0603	STD	STD
7	R18, R194, R202, R246, R248, R260, R262	Resistor, Chip, 10.0k, 1/16W, 1%, 0402	STD	STD
2	R181, R189	Resistor, Chip, 0.005, 1W, 1%, 2512	STD	STD
1	R182	Resistor, Chip, 8.06k, 1/10W, 1%, 0603	STD	STD
5	R186, R187, R188, R190, R212	Resistor, Chip, 330, 1/10W, 1%, 0603	STD	STD
1	R192	Resistor, Chip, 100, 1/10W, 1%, 0603	STD	STD
10	R193, R195, R196, R197, R198, R199, R203, R204, R206, R207	Resistor, Chip, 1M, 1/16W, 1%, 0402	STD	STD
1	R2	Resistor, Chip, 130, 1/16W, 1%, 0402	STD	STD


Table 13. EVM Major Components List (continued)

QTY	REF DES	Description	MFR	Part Number
20	R43, R49, R51, R60, R65, R71, R75, R85, R87, R93, R200, R201, R208, R209, R243, R249, R253, R254, R263, R265	Resistor, Chip, 0, 1/16W, 1%, 0402	STD	STD
1	R21	Resistor, Chip, 200k, 1/10W, 1%, 0603	STD	STD
2	R210, R211	Resistor, Chip, 3.01k, 1/10W, 1%, 0603	STD	STD
1	R224	Resistor, Chip, 75, 1/10W, 1%, 0603	STD	STD
1	R225	Resistor, Chip, 130, 1/10W, 1%, 0603	STD	STD
1	R226	Resistor, Chip, 43.2, 1/10W, 1%, 0603	STD	STD
1	R227	Resistor, Chip, 1.50k, 1/10W, 1%, 0603	STD	STD
2	R228, R229	Resistor, Chip, 33.2, 1/10W, 1%, 0603	STD	STD
1	R23	Resistor, Chip, 4.02k, 1/10W, 1%, 0603	STD	STD
2	R234, R236	Resistor, Chip, 470, 1/10W, 1%, 0603	STD	STD
1	R235	Resistor, Chip, 2.21k, 1/10W, 1%, 0603	STD	STD
2	R240, R241	Resistor, Chip, 2.74k, 1/10W, 1%, 0603	STD	STD
2	R242, R251	Resistor, Chip, 2.21, 1/16W, 1%, 0402	STD	STD
2	R244, R255	Resistor, Chip, 475k, 1/16W, 1%, 0402	STD	STD
2	R245, R257	Resistor, Chip, 5.62k, 1/16W, 1%, 0402	STD	STD
2	R252, R264	Resistor, Chip, 2.00k, 1/16W, 1%, 0402	STD	STD
1	R258	Resistor, Chip, 3.09k, 1/16W, 1%, 0402	STD	STD
1	R259	Resistor, Chip, 20.0k, 1/16W, 1%, 0402	STD	STD
7	R26, R97, R98, R114, R115, R162, R184	Resistor, Chip, 100k, 1/10W, 1%, 0603	STD	STD
1	R267	Resistor, Chip, 1.37k, 1/16W, 1%, 0603	STD	STD
1	R4	Resistor, Chip, 54.9, 1/16W, 1%, 0402	STD	STD
5	R42, R50, R64, R74, R86	Resistor, Chip, 17.8k, 1/8W, 1%, 0805	STD	STD
5	R46, R56, R68, R79, R91	Resistor, Chip, 162k, 1/10W, 1%, 0603	STD	STD
5	R48, R59, R70, R84, R92	Resistor, Chip, 28.7k, 1/10W, 1%, 0603	STD	STD
7	R5, R52, R61, R72, R80, R143, R146	Resistor, Chip, 10, 1/10W, 1%, 0603	STD	STD
1	R6	Resistor, Chip, 8.25k, 1/10W, 1%, 0603	STD	STD
2	R7, R22	Resistor, Chip, 15.4k, 1/10W, 1%, 0603	STD	STD
14	R8, R11, R14, R20, R28, R29, R32, R34, R37, R39, R135, R136, R153, R154	Resistor, Chip, 2.21, 1/10W, 1%, 0603	STD	STD
5	R94, R103, R105, R120, R121	Resistor, Chip, 39.2k, 1/10W, 1%, 0603	STD	STD
4	R95, R96, R112, R113	Resistor, Chip, 150k, 1/10W, 1%, 0603	STD	STD
4	R99, R100, R116, R117	Resistor, Chip, 75.0k, 1/10W, 1%, 0603	STD	STD
7	RT1, RT2, RT3, RT4, RT5, RT6, RT7	NTC Thermistor, 100k, 0603, 5%	Murata	NCP18WF104J03RB
1	U1	IC, 3+2 phase, IMVP-7 VCORE CPU and GPU Controller, QFN-48	TI	TPS59650RSL
1	U12	IC, Timer, Low-Power CMOS, SO-8	TI	TLC555CDR
1	U13	IC, Dual 10 ohm SPDT Analogy Switch, DGS_10P	TI	TSSA23157DGS
1	U14	IC, Nano Power, Open output comparators, PW14	TI	TLV3404IPW
1	U15	IC, USB to series port controller, QFN-32	TI	TUSB3410RHB
1	U16	IC, CMOS programmable controller, QFP-100	TI	TMS320F2808PZS
3	U17, U19, U20	IC, Dual Schmitt-trigger inverter, DCK-6	TI	SN74LVC2G07DCK
1	U18	IC, Dual-bit dual-supply bus transceiver, RSW-10	TI	SN74AVC2T245RSW
3	U2, U3, U4	IC, Dual high voltage, efficient synchronous MOSFET buck driver, QFN-8	TI	TPS51601ADRB
1	U5	IC, High performance, single synchronous step down controller, QFN-16	TI	TPS51219RTE
1	U6	IC, Complete DDR2, DDR3 and DDR3L memory power solution, QFN-20	TI	TPS51916RUK
1	U7	IC, Dual low dropout regulator, 500mA and 250mA outputs, PWP20	TI	TPS70102PWP
1	U8	IC, 150mA, low Iq, wide bandwidth, LDO, SC70	TI	TPS71712DCK

Table 13. EVM Major Components List (continued)

QTY	REF DES	Description	MFR	Part Number
1	U9	IC, Quadruple 2-input positive –AND gates, SO-14	TI	SN74HC08D
2	U10, U11	IC, Dual 4A High speed low side power MOSFET drivers, SO-8	TI	UCC27324D
1	X1	Crystal, controlled oscillators, 0.150"x0.528"	ABRACON	ABLS-20.000MHZ-B2-T
1	Y1	Crystal, controlled oscillators, 0.150"x0.528"	ABRACON	ABLS-12.000MHZ-B2-T
1	XU1	Socket, CPU	Molex	rPGA989

10 Schematics



CPU and GPU Control, 1st and 2nd Phase CPU Power

- Note 1:
- △ Not used
 - △ CPU switching frequency selection: See sheet 5
 - △ GPU switching frequency selection: See sheet 5
 - △ CPU OCP selection: See sheet 5
 - △ GPU OCP selection: See sheet 5
 - △ GPU OSR/USR selection: See sheet 5
 - △ CPU third phase: See sheet 2
 - △ GPU phase: See sheet 3

See Sheet 5 CPU OCP selection and OSR setting


See Sheet 5 for FREQ selection

See Sheet 5 for OCP selection and OSR setting

See Sheet 2 for 3rd phase


See Sheet 3 for GPU Vcore


See Sheet 5 for FREQ selection



Note2:
 Not used

CPU 3rd Phase Power








Note4:

- △ Not used
 - △ A phase can be disabled by pulling the corresponding xCSPx pin to 3.3V.
 - △ Default setting for CPU: 3 phase operation
 - △ Default setting for GPU: 2 phase operation
- CPU:
1. CPU 3 Phase operation: R47, R55, R69 open
 2. CPU 2 Phase operation: R69 used 0ohm
 3. CPU 1 Phase operation: R47, R55 used 0ohm
- GPU:
1. GPU 2 Phase operation: R83, R89 open
 2. GPU 1 Phase operation: R89 used 0ohm

**Current Feedback Selection and Filtering
Differential Voltage Feedback and termination**









Note 7:

Δ Not used

Δ S3/IS5 Enable Control, See datasheet for detail

VDDQ Power


VBAT Conversion Voltage Input:
9V -20V



NoteC:






- ⚠ Not used
- ⚠ VCCIO, GPU and CPU Dynamic Load:
- 1. Switch to "ON" position to enable the Dynamic Load
- 2. Switch to "OFF" position to disable the Dynamic Load (Default)
- ⚠ J23: Default setting: Jumper shorts on to Enable on board dynamic load


5V Bias Voltage Input



Silk:

- VCCIO_DL
- GFX_DL
- CPU_DL1
- CPU_DL2






Note9:

- △ Not used
- △ S4: IMVP-7 VR Enable:
 1. Switch to "ON" position to Enable TPS59650 controller
 2. Switch to "OFF" position to Disable TPS59650 controller(Default)
- △ Default Trim: R117 = Not used, R116 = 1.00k

Logic Signal Termination and Status LED's LED is ON when the logic signal is in the ACTIVE state

J24, J31 are labview connections for EVM testing




Note 10:
 ⚠ Not used

A2	RSVD	E29	LA9	AM9	RSVD	AT134			
A3	RSVD	E28	LA8	AM11	RSVD	AT133			
A4	RSVD	E27	LA7	AM12	RSVD	AT132			
A5	RSVD	E26	LA6	AM14	RSVD	AT131			
A6	RSVD	E25	LA5	AM15	RSVD	AT130			
A7	RSVD	E24	LA4	AM16	RSVD	AT129			
A8	RSVD	E23	LA3	AM17	RSVD	AT128			
A9	RSVD	E22	LA2	AM18	RSVD	AT127			
A10	RSVD	E21	LA1	AM19	RSVD	AT126			
A11	RSVD	E20		AM20	RSVD	AT125			
A12	RSVD	E19		AM21	RSVD	AT124			
A13	RSVD	E18		AM22	RSVD	AT123			
A14	RSVD	E17		AM23	RSVD	AT122			
A15	RSVD	E16		AM24	RSVD	AT121			
A16	RSVD	E15		AM25	RSVD	AT120			
A17	RSVD	E14		AM26	RSVD	AT119			
A18	RSVD	E13		AM27	RSVD	AT118			
A19	RSVD	E12		AM28	RSVD	AT117			
A20	RSVD	E11		AM29	RSVD	AT116			
A21	RSVD	E10		AM30	RSVD	AT115			
A22	RSVD	E9		AM31	RSVD	AT114			
A23	RSVD	E8		AM32	RSVD	AT113			
A24	RSVD	E7		AM33	RSVD	AT112			
A25	RSVD	E6		AM34	RSVD	AT111			
A26	RSVD	E5		AM35	RSVD	AT110			
A27	RSVD	E4		AM36	RSVD	AT109			
A28	RSVD	E3		AM37	RSVD	AT108			
A29	RSVD	E2		AM38	RSVD	AT107			
A30	RSVD	E1		AM39	RSVD	AT106			
A31	RSVD			AM40	RSVD	AT105			
A32	RSVD			AM41	RSVD	AT104			
A33	RSVD			AM42	RSVD	AT103			
A34	RSVD			AM43	RSVD	AT102			
A35	RSVD			AM44	RSVD	AT101			
A36	RSVD			AM45	RSVD	AT100			
A37	RSVD			AM46	RSVD	AT99			
A38	RSVD			AM47	RSVD	AT98			
A39	RSVD			AM48	RSVD	AT97			
A40	RSVD			AM49	RSVD	AT96			
A41	RSVD			AM50	RSVD	AT95			
A42	RSVD			AM51	RSVD	AT94			
A43	RSVD			AM52	RSVD	AT93			
A44	RSVD			AM53	RSVD	AT92			
A45	RSVD			AM54	RSVD	AT91			
A46	RSVD			AM55	RSVD	AT90			
A47	RSVD			AM56	RSVD	AT89			
A48	RSVD			AM57	RSVD	AT88			
A49	RSVD			AM58	RSVD	AT87			
A50	RSVD			AM59	RSVD	AT86			
A51	RSVD			AM60	RSVD	AT85			
A52	RSVD			AM61	RSVD	AT84			
A53	RSVD			AM62	RSVD	AT83			
A54	RSVD			AM63	RSVD	AT82			
A55	RSVD			AM64	RSVD	AT81			
A56	RSVD			AM65	RSVD	AT80			
A57	RSVD			AM66	RSVD	AT79			
A58	RSVD			AM67	RSVD	AT78			
A59	RSVD			AM68	RSVD	AT77			
A60	RSVD			AM69	RSVD	AT76			
A61	RSVD			AM70	RSVD	AT75			
A62	RSVD			AM71	RSVD	AT74			
A63	RSVD			AM72	RSVD	AT73			
A64	RSVD			AM73	RSVD	AT72			
A65	RSVD			AM74	RSVD	AT71			
A66	RSVD			AM75	RSVD	AT70			
A67	RSVD			AM76	RSVD	AT69			
A68	RSVD			AM77	RSVD	AT68			
A69	RSVD			AM78	RSVD	AT67			
A70	RSVD			AM79	RSVD	AT66			
A71	RSVD			AM80	RSVD	AT65			
A72	RSVD			AM81	RSVD	AT64			
A73	RSVD			AM82	RSVD	AT63			
A74	RSVD			AM83	RSVD	AT62			
A75	RSVD			AM84	RSVD	AT61			
A76	RSVD			AM85	RSVD	AT60			
A77	RSVD			AM86	RSVD	AT59			
A78	RSVD			AM87	RSVD	AT58			
A79	RSVD			AM88	RSVD	AT57			
A80	RSVD			AM89	RSVD	AT56			
A81	RSVD			AM90	RSVD	AT55			
A82	RSVD			AM91	RSVD	AT54			
A83	RSVD			AM92	RSVD	AT53			
A84	RSVD			AM93	RSVD	AT52			
A85	RSVD			AM94	RSVD	AT51			
A86	RSVD			AM95	RSVD	AT50			
A87	RSVD			AM96	RSVD	AT49			
A88	RSVD			AM97	RSVD	AT48			
A89	RSVD			AM98	RSVD	AT47			
A90	RSVD			AM99	RSVD	AT46			
A91	RSVD			AM100	RSVD	AT45			
A92	RSVD			AM101	RSVD	AT44			
A93	RSVD			AM102	RSVD	AT43			
A94	RSVD			AM103	RSVD	AT42			
A95	RSVD			AM104	RSVD	AT41			
A96	RSVD			AM105	RSVD	AT40			
A97	RSVD			AM106	RSVD	AT39			
A98	RSVD			AM107	RSVD	AT38			
A99	RSVD			AM108	RSVD	AT37			
A100	RSVD			AM109	RSVD	AT36			


B1	RSVD	E29	LA9	AM9	RSVD	AT134			
B2	RSVD	E28	LA8	AM11	RSVD	AT133			
B3	RSVD	E27	LA7	AM12	RSVD	AT132			
B4	RSVD	E26	LA6	AM14	RSVD	AT131			
B5	RSVD	E25	LA5	AM15	RSVD	AT130			
B6	RSVD	E24	LA4	AM16	RSVD	AT129			
B7	RSVD	E23	LA3	AM17	RSVD	AT128			
B8	RSVD	E22	LA2	AM18	RSVD	AT127			
B9	RSVD	E21	LA1	AM19	RSVD	AT126			
B10	RSVD	E20		AM20	RSVD	AT125			
B11	RSVD	E19		AM21	RSVD	AT124			
B12	RSVD	E18		AM22	RSVD	AT123			
B13	RSVD	E17		AM23	RSVD	AT122			
B14	RSVD	E16		AM24	RSVD	AT121			
B15	RSVD	E15		AM25	RSVD	AT120			
B16	RSVD	E14		AM26	RSVD	AT119			
B17	RSVD	E13		AM27	RSVD	AT118			
B18	RSVD	E12		AM28	RSVD	AT117			
B19	RSVD	E11		AM29	RSVD	AT116			
B20	RSVD	E10		AM30	RSVD	AT115			
B21	RSVD	E9		AM31	RSVD	AT114			
B22	RSVD	E8		AM32	RSVD	AT113			
B23	RSVD	E7		AM33	RSVD	AT112			
B24	RSVD	E6		AM34	RSVD	AT111			
B25	RSVD	E5		AM35	RSVD	AT110			
B26	RSVD	E4		AM36	RSVD	AT109			
B27	RSVD	E3		AM37	RSVD	AT108			
B28	RSVD	E2		AM38	RSVD	AT107			
B29	RSVD	E1		AM39	RSVD	AT106			
B30	RSVD			AM40	RSVD	AT105			
B31	RSVD			AM41	RSVD	AT104			
B32	RSVD			AM42	RSVD	AT103			
B33	RSVD			AM43	RSVD	AT102			
B34	RSVD			AM44	RSVD	AT101			
B35	RSVD			AM45	RSVD	AT100			
B36	RSVD			AM46	RSVD	AT99			
B37	RSVD			AM47	RSVD	AT98			
B38	RSVD			AM48	RSVD	AT97			
B39	RSVD			AM49	RSVD	AT96			
B40	RSVD			AM50	RSVD	AT95			
B41	RSVD			AM51	RSVD	AT94			
B42	RSVD			AM52	RSVD	AT93			
B43	RSVD			AM53	RSVD	AT92			
B44	RSVD			AM54	RSVD	AT91			
B45	RSVD			AM55	RSVD	AT90			
B46	RSVD			AM56	RSVD	AT89			
B47	RSVD			AM57	RSVD	AT88			
B48	RSVD			AM58	RSVD	AT87			
B49	RSVD			AM59	RSVD	AT86			
B50	RSVD			AM60	RSVD	AT85			
B51	RSVD			AM61	RSVD	AT84			
B52	RSVD			AM62	RSVD	AT83			
B53	RSVD			AM63	RSVD	AT82			
B54	RSVD			AM64	RSVD	AT81			
B55	RSVD			AM65	RSVD	AT80			
B56	RSVD			AM66	RSVD	AT79			
B57	RSVD			AM67	RSVD	AT78			
B58	RSVD			AM68	RSVD	AT77			
B59	RSVD			AM69	RSVD	AT76			
B60	RSVD			AM70	RSVD	AT75			
B61	RSVD			AM71	RSVD	AT74			
B62	RSVD			AM72	RSVD	AT73			
B63	RSVD			AM73	RSVD	AT72			
B64	RSVD			AM74	RSVD	AT71			
B65	RSVD			AM75	RSVD	AT70			
B66	RSVD			AM76	RSVD	AT69			
B67	RSVD			AM77	RSVD	AT68			
B68	RSVD			AM78	RSVD	AT67			
B69	RSVD			AM79	RSVD	AT66			
B70	RSVD			AM80	RSVD	AT65			
B71	RSVD			AM81	RSVD	AT64			
B72	RSVD			AM82	RSVD	AT63			
B73	RSVD			AM83	RSVD	AT62			
B74	RSVD			AM84	RSVD	AT61			
B75	RSVD			AM85	RSVD	AT60			
B76	RSVD			AM86	RSVD	AT59			
B77	RSVD			AM87	RSVD	AT58			
B78	RSVD			AM88	RSVD	AT57			
B79	RSVD			AM89	RSVD	AT56			
B80	RSVD			AM90	RSVD	AT55			
B81	RSVD			AM91	RSVD	AT54			
B82	RSVD			AM92	RSVD	AT53			
B83	RSVD			AM93	RSVD	AT52			
B84	RSVD			AM94	RSVD	AT51			

Jumper to use 5V from USB




Note 1:

- 1 Not used
- 2 5V Bias option:
 - 1. Jumper shorts on J33, 5V Bias used from USB. If USB 5V is used, external 5V supply from J22 should not be used.
 - 2. No Jumper shorts on J33, 5V Bias used from external J22 (Default)
- 3 For Internal software development



USB to DSP



Optional Solution for VCCIO and VDDQ

Note 13:
 Not used

J42, J43: Optional VCCIO and VDDQ Enable
 1. Jumper shorts on J42, J43 to Enable Optional VCCIO and VDDQ
 2. No Jumper shorts on J42, J43 to Disable Optional VCCIO and VDDQ

EVALUATION BOARD/KIT/MODULE (EVM) ADDITIONAL TERMS

Texas Instruments (TI) provides the enclosed Evaluation Board/Kit/Module (EVM) under the following conditions:

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING LIMITED WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please visit www.ti.com/esh or contact TI.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used. TI currently deals with a variety of customers for products, and therefore our arrangement with the user is not exclusive. TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

REGULATORY COMPLIANCE INFORMATION

As noted in the EVM User's Guide and/or EVM itself, this EVM and/or accompanying hardware may or may not be subject to the Federal Communications Commission (FCC) and Industry Canada (IC) rules.

For EVMs **not** subject to the above rules, this evaluation board/kit/module is intended for use for ENGINEERING DEVELOPMENT, DEMONSTRATION OR EVALUATION PURPOSES ONLY and is not considered by TI to be a finished end product fit for general consumer use. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC or ICES-003 rules, which are designed to provide reasonable protection against radio frequency interference. Operation of the equipment may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

General Statement for EVMs including a radio

User Power/Frequency Use Obligations: This radio is intended for development/professional use only in legally allocated frequency and power limits. Any use of radio frequencies and/or power availability of this EVM and its development application(s) must comply with local laws governing radio spectrum allocation and power limits for this evaluation module. It is the user's sole responsibility to only operate this radio in legally acceptable frequency space and within legally mandated power limitations. Any exceptions to this are strictly prohibited and unauthorized by Texas Instruments unless user has obtained appropriate experimental/development licenses from local regulatory authorities, which is responsibility of user including its acceptable authorization.

For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant

Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement for Class A EVM devices

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Interference Statement for Class B EVM devices

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For EVMs annotated as IC – INDUSTRY CANADA Compliant

This Class A or B digital apparatus complies with Canadian ICES-003.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Concerning EVMs including radio transmitters

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Concerning EVMs including detachable antennas

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Cet appareil numérique de la classe A ou B est conforme à la norme NMB-003 du Canada.

Les changements ou les modifications pas expressément approuvés par la partie responsable de la conformité ont pu vider l'autorité de l'utilisateur pour actionner l'équipement.

Concernant les EVMs avec appareils radio

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

【Important Notice for Users of this Product in Japan】

This development kit is NOT certified as Confirming to Technical Regulations of Radio Law of Japan

If you use this product in Japan, you are required by Radio Law of Japan to follow the instructions below with respect to this product:

1. Use this product in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use this product only after you obtained the license of Test Radio Station as provided in Radio Law of Japan with respect to this product, or
3. Use of this product only after you obtained the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to this product. Also, please do not transfer this product, unless you give the same notice above to the transferee. Please note that if you could not follow the instructions above, you will be subject to penalties of Radio Law of Japan.

Texas Instruments Japan Limited
(address) 24-1, Nishi-Shinjuku 6 chome, Shinjuku-ku, Tokyo, Japan

<http://www.tij.co.jp>

【ご使用にあたっての注】

本開発キットは技術基準適合証明を受けておりません。

本製品のご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。

日本テキサス・インスツルメンツ株式会社
東京都新宿区西新宿6丁目24番1号
西新宿三井ビル

<http://www.tij.co.jp>

EVALUATION BOARD/KIT/MODULE (EVM) WARNINGS, RESTRICTIONS AND DISCLAIMERS

For Feasibility Evaluation Only, in Laboratory/Development Environments. Unless otherwise indicated, this EVM is not a finished electrical equipment and not intended for consumer use. It is intended solely for use for preliminary feasibility evaluation in laboratory/development environments by technically qualified electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems and subsystems. It should not be used as all or part of a finished end product.

Your Sole Responsibility and Risk. You acknowledge, represent and agree that:

1. You have unique knowledge concerning Federal, State and local regulatory requirements (including but not limited to Food and Drug Administration regulations, if applicable) which relate to your products and which relate to your use (and/or that of your employees, affiliates, contractors or designees) of the EVM for evaluation, testing and other purposes.
2. You have full and exclusive responsibility to assure the safety and compliance of your products with all such laws and other applicable regulatory requirements, and also to assure the safety of any activities to be conducted by you and/or your employees, affiliates, contractors or designees, using the EVM. Further, you are responsible to assure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard.
3. You will employ reasonable safeguards to ensure that your use of the EVM will not result in any property damage, injury or death, even if the EVM should fail to perform as described or expected.
4. You will take care of proper disposal and recycling of the EVM's electronic components and packing materials.

Certain Instructions. It is important to operate this EVM within TI's recommended specifications and environmental considerations per the user guidelines. Exceeding the specified EVM ratings (including but not limited to input and output voltage, current, power, and environmental ranges) may cause property damage, personal injury or death. If there are questions concerning these ratings please contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, some circuit components may have case temperatures greater than 60°C as long as the input and output are maintained at a normal ambient operating temperature. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors which can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during normal operation, please be aware that these devices may be very warm to the touch. As with all electronic evaluation tools, only qualified personnel knowledgeable in electronic measurement and diagnostics normally found in development environments should use these EVMs.

Agreement to Defend, Indemnify and Hold Harmless. You agree to defend, indemnify and hold TI, its licensors and their representatives harmless from and against any and all claims, damages, losses, expenses, costs and liabilities (collectively, "Claims") arising out of or in connection with any use of the EVM that is not in accordance with the terms of the agreement. This obligation shall apply whether Claims arise under law of tort or contract or any other legal theory, and even if the EVM fails to perform as described or expected.

Safety-Critical or Life-Critical Applications. If you intend to evaluate the components for possible use in safety critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, such as devices which are classified as FDA Class III or similar classification, then you must specifically notify TI of such intent and enter into a separate Assurance and Indemnity Agreement.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2012, Texas Instruments Incorporated

EVALUATION BOARD/KIT/MODULE (EVM) ADDITIONAL TERMS

Texas Instruments (TI) provides the enclosed Evaluation Board/Kit/Module (EVM) under the following conditions:

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING LIMITED WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please visit www.ti.com/esh or contact TI.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used. TI currently deals with a variety of customers for products, and therefore our arrangement with the user is not exclusive. TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

REGULATORY COMPLIANCE INFORMATION

As noted in the EVM User's Guide and/or EVM itself, this EVM and/or accompanying hardware may or may not be subject to the Federal Communications Commission (FCC) and Industry Canada (IC) rules.

For EVMs **not** subject to the above rules, this evaluation board/kit/module is intended for use for ENGINEERING DEVELOPMENT, DEMONSTRATION OR EVALUATION PURPOSES ONLY and is not considered by TI to be a finished end product fit for general consumer use. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC or ICES-003 rules, which are designed to provide reasonable protection against radio frequency interference. Operation of the equipment may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

General Statement for EVMs including a radio

User Power/Frequency Use Obligations: This radio is intended for development/professional use only in legally allocated frequency and power limits. Any use of radio frequencies and/or power availability of this EVM and its development application(s) must comply with local laws governing radio spectrum allocation and power limits for this evaluation module. It is the user's sole responsibility to only operate this radio in legally acceptable frequency space and within legally mandated power limitations. Any exceptions to this are strictly prohibited and unauthorized by Texas Instruments unless user has obtained appropriate experimental/development licenses from local regulatory authorities, which is responsibility of user including its acceptable authorization.

For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant

Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement for Class A EVM devices

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Interference Statement for Class B EVM devices

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For EVMs annotated as IC – INDUSTRY CANADA Compliant

This Class A or B digital apparatus complies with Canadian ICES-003.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Concerning EVMs including radio transmitters

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Concerning EVMs including detachable antennas

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Cet appareil numérique de la classe A ou B est conforme à la norme NMB-003 du Canada.

Les changements ou les modifications pas expressément approuvés par la partie responsable de la conformité ont pu vider l'autorité de l'utilisateur pour actionner l'équipement.

Concernant les EVMs avec appareils radio

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

【Important Notice for Users of this Product in Japan】

This development kit is NOT certified as Confirming to Technical Regulations of Radio Law of Japan

If you use this product in Japan, you are required by Radio Law of Japan to follow the instructions below with respect to this product:

1. Use this product in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use this product only after you obtained the license of Test Radio Station as provided in Radio Law of Japan with respect to this product, or
3. Use of this product only after you obtained the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to this product. Also, please do not transfer this product, unless you give the same notice above to the transferee. Please note that if you could not follow the instructions above, you will be subject to penalties of Radio Law of Japan.

Texas Instruments Japan Limited
(address) 24-1, Nishi-Shinjuku 6 chome, Shinjuku-ku, Tokyo, Japan

<http://www.tij.co.jp>

【ご使用にあたっての注】

本開発キットは技術基準適合証明を受けておりません。

本製品のご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。

日本テキサス・インスツルメンツ株式会社
東京都新宿区西新宿6丁目24番1号
西新宿三井ビル

<http://www.tij.co.jp>

EVALUATION BOARD/KIT/MODULE (EVM) WARNINGS, RESTRICTIONS AND DISCLAIMERS

For Feasibility Evaluation Only, in Laboratory/Development Environments. Unless otherwise indicated, this EVM is not a finished electrical equipment and not intended for consumer use. It is intended solely for use for preliminary feasibility evaluation in laboratory/development environments by technically qualified electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems and subsystems. It should not be used as all or part of a finished end product.

Your Sole Responsibility and Risk. You acknowledge, represent and agree that:

1. You have unique knowledge concerning Federal, State and local regulatory requirements (including but not limited to Food and Drug Administration regulations, if applicable) which relate to your products and which relate to your use (and/or that of your employees, affiliates, contractors or designees) of the EVM for evaluation, testing and other purposes.
2. You have full and exclusive responsibility to assure the safety and compliance of your products with all such laws and other applicable regulatory requirements, and also to assure the safety of any activities to be conducted by you and/or your employees, affiliates, contractors or designees, using the EVM. Further, you are responsible to assure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard.
3. You will employ reasonable safeguards to ensure that your use of the EVM will not result in any property damage, injury or death, even if the EVM should fail to perform as described or expected.
4. You will take care of proper disposal and recycling of the EVM's electronic components and packing materials.

Certain Instructions. It is important to operate this EVM within TI's recommended specifications and environmental considerations per the user guidelines. Exceeding the specified EVM ratings (including but not limited to input and output voltage, current, power, and environmental ranges) may cause property damage, personal injury or death. If there are questions concerning these ratings please contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, some circuit components may have case temperatures greater than 60°C as long as the input and output are maintained at a normal ambient operating temperature. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors which can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during normal operation, please be aware that these devices may be very warm to the touch. As with all electronic evaluation tools, only qualified personnel knowledgeable in electronic measurement and diagnostics normally found in development environments should use these EVMs.

Agreement to Defend, Indemnify and Hold Harmless. You agree to defend, indemnify and hold TI, its licensors and their representatives harmless from and against any and all claims, damages, losses, expenses, costs and liabilities (collectively, "Claims") arising out of or in connection with any use of the EVM that is not in accordance with the terms of the agreement. This obligation shall apply whether Claims arise under law of tort or contract or any other legal theory, and even if the EVM fails to perform as described or expected.

Safety-Critical or Life-Critical Applications. If you intend to evaluate the components for possible use in safety critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, such as devices which are classified as FDA Class III or similar classification, then you must specifically notify TI of such intent and enter into a separate Assurance and Indemnity Agreement.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2012, Texas Instruments Incorporated

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components which meet ISO/TS16949 requirements, mainly for automotive use. Components which have not been so designated are neither designed nor intended for automotive use; and TI will not be responsible for any failure of such components to meet such requirements.

Products

Audio	www.ti.com/audio
Amplifiers	amplifier.ti.com
Data Converters	dataconverter.ti.com
DLP® Products	www.dlp.com
DSP	dsp.ti.com
Clocks and Timers	www.ti.com/clocks
Interface	interface.ti.com
Logic	logic.ti.com
Power Mgmt	power.ti.com
Microcontrollers	microcontroller.ti.com
RFID	www.ti-rfid.com
OMAP Applications Processors	www.ti.com/omap
Wireless Connectivity	www.ti.com/wirelessconnectivity

Applications

Automotive and Transportation	www.ti.com/automotive
Communications and Telecom	www.ti.com/communications
Computers and Peripherals	www.ti.com/computers
Consumer Electronics	www.ti.com/consumer-apps
Energy and Lighting	www.ti.com/energy
Industrial	www.ti.com/industrial
Medical	www.ti.com/medical
Security	www.ti.com/security
Space, Avionics and Defense	www.ti.com/space-avionics-defense
Video and Imaging	www.ti.com/video

TI E2E Community

e2e.ti.com