

## **THS4532 EVM Evaluation Module**

The THS4532 EVM is an evaluation module for the dual THS4532 amplifier in the PW [16-lead TSSOP] package. This evaluation module is designed to quickly and easily demonstrate the functionality and versatility of the amplifier. The EVM is ready to connect to power, signal source, and test instruments through the use of onboard connectors. The EVM comes configured for easy connection with common 50- $\Omega$  laboratory equipment on its inputs and outputs. The amplifier is configured for single-ended input with gain of 1 V/V to differential output at the device pins, which is converted to single-ended via a transformer to the output. It can be easily configured for other functions, gains, and single- or split-supply operation.

### **Contents**

1	Features .....	1
2	EVM Specifications .....	2
3	Power Connections .....	2
3.1	Split-Supply Operation .....	2
3.2	Single-Supply Operation .....	2
4	Input and Output Connections .....	2
5	THS4532 EVM Schematic, Layout, and Bill of Materials .....	3
5.1	Schematics .....	3
5.2	THS4532 EVM Layers .....	5
5.3	Bill of Materials .....	9

### **List of Figures**

1	THS4532 EVM Schematic 1 of 2 .....	3
2	THS4532 EVM Schematic 2 of 2 .....	4
3	THS4532 EVM Top Layer 1 .....	5
4	THS4532 EVM Ground Layer 2 .....	6
5	THS4532 EVM Ground Layer 3 .....	7
6	THS4532 EVM Bottom Layer 4 .....	8

### **List of Tables**

1	THS4532 EVM Bill of Materials .....	9
---	-------------------------------------	---

### **1 Features**

- Configured for split-supply operation and easily modified for single supply
- Default gain of 1 configuration can easily be reconfigured for other gains
- Designed for easy connection to standard 50- $\Omega$  input/output impedance test equipment
- Inputs and outputs include SMA connectors

## 2 EVM Specifications

	Single-supply voltage range ( $V_{S-}$ = ground)	2.5 V to 5.5 V
$V_{S\pm}$	Split-supply voltage range	$\pm 1.25$ V to $\pm 2.75$ V
$I_{S\pm}$	Supply current	250 $\mu$ A
	Input voltage	$V_{S\pm}$ , Max
$I_{OUT}$	Output drive	$\pm 25$ mA

## 3 Power Connections

The THS4532 EVM is equipped with banana jacks for easy connection of power. The positive supply input is labeled  $V_{S+}$ . The negative supply input is labeled  $V_{S-}$ . Ground is labeled GND.

### 3.1 Split-Supply Operation

To operate as split supply, apply the positive supply voltage to  $V_{S+}$ , negative supply voltage to  $V_{S-}$ , and the ground reference from supply to GND.

### 3.2 Single-Supply Operation

To operate as single supply, connect jumper  $V_{S-}$  to GND, and apply the positive supply voltage to  $V_{S+}$ . Inputs and outputs must be biased per data-sheet specifications for proper operation.


## 4 Input and Output Connections

The THS4532 EVM is equipped with SMA connectors for easy connection of signal generators and analysis equipment. As shipped, the EVM is configured for a gain of 1, split supply, single-ended input and output with 50- $\Omega$  termination. For best results, signals must be routed to and from the EVM with cables having 50- $\Omega$  characteristic impedance.  $V_{IN1+}$  (J2) and  $V_{IN2+}$  (J9) are the input connectors for single-ended input signals for channel 1 and 2 respectively.  $V_{OUT1+}$  (J6) and  $V_{OUT1-}$  (J10) are the output connectors for single-ended output signals for channels 1 and 2 respectively.  $V_{IN1-}$  (J1) and  $V_{IN2-}$  (J8) are not intended for use with single-ended input signals and has C2 and R9 added for channel 1 and C18 and R35 for channel 2 to approximate the impedance of an ac-coupled 50- $\Omega$  source and to balance the amplifier when  $V_{IN1+}$  or  $V_{IN2+}$  is driven from an ac-coupled, 50- $\Omega$  source. The amplifier converts the single-ended input to a differential signal at its output pins. A resistor network (R16, R17, R18 for channel 1 and R42, R43, R44 for channel 2) and transformer on the amplifier's output convert the differential signal to single-ended, provides 2-k $\Omega$  load to the amplifier when terminated in 50  $\Omega$ , and 50- $\Omega$  line impedance match at  $V_{OUT1+}$  and  $V_{OUT2+}$ . This results in loss, and the overall gain is approximately -38 dB. See the following THS4532 data-sheet applications section, schematics, and layouts for more detail and how to reconfigure the EVM.

## 5 THS4532 EVM Schematic, Layout, and Bill of Materials

### 5.1 Schematics

Figure 1 and Figure 2 illustrate the EVM schematics.



**Figure 1. THS4532 EVM Schematic 1 of 2**





Figure 2. THS4532 EVM Schematic 2 of 2

## 5.2 THS4532 EVM Layers

Figure 3 through Figure 5 illustrate the PCB layers of the EVM.



**Figure 3. THS4532 EVM Top Layer 1**






Figure 4. THS4532 EVM Ground Layer 2



**Figure 5. THS4532 EVM Ground Layer 3**



**Figure 6. THS4532 EVM Bottom Layer 4**

### 5.3 Bill of Materials

**Table 1. THS4532 EVM Bill of Materials**

ITEM	QTY	REFERENCE	VALUE	DESCRIPTION	PKG/CASE	MANUFACTURER	MANUFACTURER	DISTRIBUTOR	DISTRIBUTOR
		DESIGNATOR					PART NUMBER		PART NUMBER
1	4	C7, C8, C9, C10	10.0uF	CAP, TAN, 16V, X7R	1206	AVX	1206YC106KAT2A	DIGI-KEY	478-5725-1-ND
2	4	C3, C5, C11, C12	0.1uF	CAP, CERAMIC, 16V, X7R	0603	AVX	0603YC104KAT2A	DIGI-KEY	478-1239-1-ND
3	6	C2, C4, C6, C18, C19, C20	0.22uF	CAP, CERAMIC, 10V, X7R	0603	AVX	0603ZC224KAT2A	DIGI-KEY	478-1243-1-ND
4	10	C1, C13, C14, C15, C16, C17, C21, C22, C23, C24		OPEN	0603				
5	4	R10, R11, R36, R37	51.1	RESISTOR, 1/16W, 1%	0402	PANASONIC	ERJ-2RKF51R1X	DIGI-KEY	P51.1LCT-ND
6	4	R16, R17, R42, R43	976	RESISTOR, 1/16W, 1%	0402	PANASONIC	ERJ-2RKF9760X	DIGI-KEY	P976LCT-ND
7	8	R12, R13, R14, R15, R38, R39, R40, R41	2K	RESISTOR, 1/16W, 1%	0402	PANASONIC	ERJ-2RKF2001X	DIGI-KEY	P2.00KLCT-ND
8	20	R1, R2, R3, R6, R7, R8, R19, R22, R23, R26, R27, R28, R29, R32, R33, R34, R45, R48, R49, R52		OPEN	0603				
9	4	R24, R25, R50, R51	0	RESISTOR	0603	ROHM	TRR03EZPJ000	DIGI-KEY	RHM0.0BKCT-ND
10	2	R9, R35	49.9	RESISTOR, 1/10W, 1%	0603	ROHM	MCR03ERTF49R9	DIGI-KEY	RHM49.9CFCT-ND
11	2	R18, R44	51.1	RESISTOR, 1/10W, 1%	0603	PANASONIC	ERJ-3EKF51R1V	DIGI-KEY	P51.1HCT-ND
12	4	R20, R21, R46, R47		OPEN					
13	4	R4, R5, R30, R31	0	RESISTOR	0805	ROHM	MCR10EZPJ000	DIGI-KEY	RHM0.0ARCT-ND
14	4	R53, R54, R55, R56	10K	RESISTOR	0805	ROHM	MCR10ERTF1002	DIGI-KEY	RHM10.0KCHCT-ND
15	2	T1, T3		OPEN					
16	2	T2, T4		TRANSFORMER, RF		MINI-CIRCUITS	ADT1-1WT+		
17	8	J1, J7, J8, J11, J12, J13, J14, J15		OPEN					
18	3	J3, J4, J5		JACK, BANANA RECEPTANCE		TENMA	SPC15459	NEWARK	79K5034
19	4	J2, J6, J9, J10		CONNECTOR, EDGE, SMA PCB JACK		JOHNSON	142-0701-801	NEWARK	90F2624
20	2	JP1, JP2	3POS	HEADER, 0.1" CTRS, 0.025" SQ. PINS		SULLINS	PBC03SAAN	DIGI-KEY	S1011E-03-ND
21	2	JP1, JP2		SHUNTS		SULLINS	SSC02SYAN	DIGI-KEY	S9002-ND
22	2	TP1, TP4		TESTPOINT, RED		KEYSTONE	5000	DIGI-KEY	5000K-ND
23	2	TP2, TP3		TESTPOINT, BLACK		KEYSTONE	5001	DIGI-KEY	5001K-ND
24	1	U1		IC, THS4532	PW	TI	THS4532IPW		
25	4			STANDOFF, 4-40 HEX, 0.625" LENGTH		KEYSTONE	1808	DIGI-KEY	1808K-ND
26	4			SCREW, PHILLIPS, 4-40, .250"			PMSSS 440 0025 PH	DIGI-KEY	H703-ND
27	1			BOARD, PRINTED CIRCUIT		TI	EDGE # 6553528		
Notes:									
1. These assemblies are ESD sensitive, observe ESD precautions. Use of no-clean flux is not acceptable.									
2. These assemblies must be clean and free from flux and all contaminants.									
3. These assemblies must comply with workmanship standards IPC-A-610 Class 2.									
4. Ref designators marked with an asterisk (**) cannot be substituted. All other components can be substituted with equivalent MFG's components.									



## Evaluation Board/Kit Important Notice

Texas Instruments (TI) provides the enclosed product(s) under the following conditions:

This evaluation board/kit is intended for use for **ENGINEERING DEVELOPMENT, DEMONSTRATION, OR EVALUATION PURPOSES ONLY** and is not considered by TI to be a finished end-product fit for general consumer use. Persons handling the product(s) must have electronics training and observe good engineering practice standards. As such, the goods being provided are not intended to be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety and environmental measures typically found in end products that incorporate such semiconductor components or circuit boards. This evaluation board/kit does not fall within the scope of the European Union directives regarding electromagnetic compatibility, restricted substances (RoHS), recycling (WEEE), FCC, CE or UL, and therefore may not meet the technical requirements of these directives or other related directives.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within 30 days from the date of delivery for a full refund. **THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.**

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

**EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.**

TI currently deals with a variety of customers for products, and therefore our arrangement with the user is **not exclusive**.

TI assumes **no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein**.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please contact the TI application engineer or visit [www.ti.com/esh](http://www.ti.com/esh).

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used.

## FCC Warning

This evaluation board/kit is intended for use for **ENGINEERING DEVELOPMENT, DEMONSTRATION, OR EVALUATION PURPOSES ONLY** and is not considered by TI to be a finished end-product fit for general consumer use. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC rules, which are designed to provide reasonable protection against radio frequency interference. Operation of this equipment in other environments may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

## EVM Warnings and Restrictions

It is important to operate this EVM within the input voltage range of 2.5 V to 5.5 V and the output voltage range of 2.5 V to 5.5 V.

Exceeding the specified input range may cause unexpected operation and/or irreversible damage to the EVM. If there are questions concerning the input range, please contact a TI field representative prior to connecting the input power.

Applying loads outside of the specified output range may result in unintended operation and/or possible permanent damage to the EVM. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative.

During normal operation, some circuit components may have case temperatures greater than 85°C. The EVM is designed to operate properly with certain components above 85°C as long as the input and output ranges are maintained. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors. These types of devices can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during operation, please be aware that these devices may be very warm to the touch.

## EVALUATION BOARD/KIT/MODULE (EVM) ADDITIONAL TERMS

Texas Instruments (TI) provides the enclosed Evaluation Board/Kit/Module (EVM) under the following conditions:

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING LIMITED WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please visit [www.ti.com/esh](http://www.ti.com/esh) or contact TI.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used. TI currently deals with a variety of customers for products, and therefore our arrangement with the user is not exclusive. TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

## REGULATORY COMPLIANCE INFORMATION

As noted in the EVM User's Guide and/or EVM itself, this EVM and/or accompanying hardware may or may not be subject to the Federal Communications Commission (FCC) and Industry Canada (IC) rules.

For EVMs **not** subject to the above rules, this evaluation board/kit/module is intended for use for ENGINEERING DEVELOPMENT, DEMONSTRATION OR EVALUATION PURPOSES ONLY and is not considered by TI to be a finished end product fit for general consumer use. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC or ICES-003 rules, which are designed to provide reasonable protection against radio frequency interference. Operation of the equipment may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

### General Statement for EVMs including a radio

*User Power/Frequency Use Obligations:* This radio is intended for development/professional use only in legally allocated frequency and power limits. Any use of radio frequencies and/or power availability of this EVM and its development application(s) must comply with local laws governing radio spectrum allocation and power limits for this evaluation module. It is the user's sole responsibility to only operate this radio in legally acceptable frequency space and within legally mandated power limitations. Any exceptions to this are strictly prohibited and unauthorized by Texas Instruments unless user has obtained appropriate experimental/development licenses from local regulatory authorities, which is responsibility of user including its acceptable authorization.

### For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant

#### Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### FCC Interference Statement for Class A EVM devices

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

#### **FCC Interference Statement for Class B EVM devices**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **For EVMs annotated as IC – INDUSTRY CANADA Compliant**

This Class A or B digital apparatus complies with Canadian ICES-003.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### **Concerning EVMs including radio transmitters**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### **Concerning EVMs including detachable antennas**

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Cet appareil numérique de la classe A ou B est conforme à la norme NMB-003 du Canada.

Les changements ou les modifications pas expressément approuvés par la partie responsable de la conformité ont pu vider l'autorité de l'utilisateur pour actionner l'équipement.

#### **Concernant les EVMs avec appareils radio**

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### **Concernant les EVMs avec antennes détachables**

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

## 【Important Notice for Users of this Product in Japan】

### This development kit is NOT certified as Confirming to Technical Regulations of Radio Law of Japan

If you use this product in Japan, you are required by Radio Law of Japan to follow the instructions below with respect to this product:

1. Use this product in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use this product only after you obtained the license of Test Radio Station as provided in Radio Law of Japan with respect to this product, or
3. Use of this product only after you obtained the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to this product. Also, please do not transfer this product, unless you give the same notice above to the transferee. Please note that if you could not follow the instructions above, you will be subject to penalties of Radio Law of Japan.

**Texas Instruments Japan Limited**  
(address) 24-1, Nishi-Shinjuku 6 chome, Shinjuku-ku, Tokyo, Japan

<http://www.tij.co.jp>

### 【ご使用にあたっての注】

本開発キットは技術基準適合証明を受けておりません。

本製品のご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。

日本テキサス・インスツルメンツ株式会社

東京都新宿区西新宿6丁目24番1号

西新宿三井ビル

<http://www.tij.co.jp>

## **EVALUATION BOARD/KIT/MODULE (EVM) WARNINGS, RESTRICTIONS AND DISCLAIMERS**

**For Feasibility Evaluation Only, in Laboratory/Development Environments.** Unless otherwise indicated, this EVM is not a finished electrical equipment and not intended for consumer use. It is intended solely for use for preliminary feasibility evaluation in laboratory/development environments by technically qualified electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems and subsystems. It should not be used as all or part of a finished end product.

Your Sole Responsibility and Risk. You acknowledge, represent and agree that:

1. You have unique knowledge concerning Federal, State and local regulatory requirements (including but not limited to Food and Drug Administration regulations, if applicable) which relate to your products and which relate to your use (and/or that of your employees, affiliates, contractors or designees) of the EVM for evaluation, testing and other purposes.
2. You have full and exclusive responsibility to assure the safety and compliance of your products with all such laws and other applicable regulatory requirements, and also to assure the safety of any activities to be conducted by you and/or your employees, affiliates, contractors or designees, using the EVM. Further, you are responsible to assure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard.
3. You will employ reasonable safeguards to ensure that your use of the EVM will not result in any property damage, injury or death, even if the EVM should fail to perform as described or expected.
4. You will take care of proper disposal and recycling of the EVM's electronic components and packing materials.

**Certain Instructions.** It is important to operate this EVM within TI's recommended specifications and environmental considerations per the user guidelines. Exceeding the specified EVM ratings (including but not limited to input and output voltage, current, power, and environmental ranges) may cause property damage, personal injury or death. If there are questions concerning these ratings please contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, some circuit components may have case temperatures greater than 60°C as long as the input and output are maintained at a normal ambient operating temperature. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors which can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during normal operation, please be aware that these devices may be very warm to the touch. As with all electronic evaluation tools, only qualified personnel knowledgeable in electronic measurement and diagnostics normally found in development environments should use these EVMs.

**Agreement to Defend, Indemnify and Hold Harmless.** You agree to defend, indemnify and hold TI, its licensors and their representatives harmless from and against any and all claims, damages, losses, expenses, costs and liabilities (collectively, "Claims") arising out of or in connection with any use of the EVM that is not in accordance with the terms of the agreement. This obligation shall apply whether Claims arise under law of tort or contract or any other legal theory, and even if the EVM fails to perform as described or expected.

**Safety-Critical or Life-Critical Applications.** If you intend to evaluate the components for possible use in safety critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, such as devices which are classified as FDA Class III or similar classification, then you must specifically notify TI of such intent and enter into a separate Assurance and Indemnity Agreement.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2012, Texas Instruments Incorporated

## IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you fully indemnify TI and its representatives against any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](#), [TI's General Quality Guidelines](#), or other applicable terms available either on [ti.com](#) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products. Unless TI explicitly designates a product as custom or customer-specified, TI products are standard, catalog, general purpose devices.

TI objects to and rejects any additional or different terms you may propose.

Copyright © 2026, Texas Instruments Incorporated

Last updated 10/2025