## Technical Article Reducing Solution Size with PMBus in Multi-rail Systems



George Lakkas

You can find hardware systems with multiple low-voltage rails that need regulation, sequencing and monitoring in cloud infrastructure equipment like base stations, networking switches, servers and storage, as well as test and measurement applications such as integrated circuit (IC) testers, oscilloscopes and network analyzers.

The Power Management Bus (PMBus) digital interface is a popular interface, which I discussed in another blog post, "A PMBus primer: common PMBus questions answered."

TI has a complete PMBus power solution for systems using  $48V_{DC}$  on the front end and  $12V_{DC}$  or another low-voltage DC rail as the intermediate bus; see Figure 1.




Figure 1. 48V to Point-of-load PMBus Power System

The benefits of a complete PMBus solution in multirail systems are many: ease of use; reduced design time (as a new design can be generated in seconds by reconfiguring the on-chip nonvolatile memory [NVM]); reduction in overall component count and total solution cost; a unified and seamless design and programming method through a single graphical user interface (GUI); much simpler board characterization through PMBus margining; and improved diagnostics through voltage, current, temperature, power and fault monitoring.

Multirail PMBus sequencers/managers such as the 24-rail UCD90240 and the new 32-rail UCD90320 can sequence, margin, monitor and report faults for up to 32 rails using TI's Fusion Digital Power™ GUI. They can also be stacked in fours for up to 128 rails, managed through the SYNC\_CLK pin if needed.

1



Additionally, the UCD90240 and UCD90320 have true black-box logging that provides detailed information about all rails, General Purpose Input (GPI), and General Purpose Output (GPO) status on the first fault, as shown in Figure 2.

Fault Fault ID Time Sti	1		T UV I Say, 3					06:15	5.004		_	-	Fault	Value	H: 0	v														_					 	-
GPI	Status	es			_					_										_																
GP1 #:	1	2	3	4	5	4	7	8		10	11	12	13	14	15	16	17	18	19	20	21	22	22	24	25	25	27	28	29	30	31	32				
		6	1	8	10	8		1		1	1	1		8	-	-	1	8	-		10	8	1	12	1		1	1			8	1				
- GPO	Status	ses		-	_	_		_				_	_	-							-						_		_	_	_		_	_		
GPO #	1	2	3	4	5		7	8	. 8	10	11	12	53	94	15	- 16																				
		<b>N</b>		<b>N</b>		1	R	9			1	-			R	1																				
Rail #	ov w	ARI		v w	ARN	oc	WAR		TOFF	WAJ	01	от и	ARIN	Ve	Itag	e		Cur	rrent	ş	1	Ter	nper	atur	•										ń	
1	1.0		Т	1	1					10)		1	0	Ī		0.2	778 V				N/A	5		13	N/A											
2	1.0			1	1)					8		1	1	T		0.2	158 V				N/A	1		3	N/A											
3	1.0	18	-	18	1	-	[826]	-	-	101	-	1	1	-	-	0.1	973 V	1	-	-	N/A	8	-	0	N/A											

Figure 2. UCD90240/UCD90320 Black-box Logging

UCD90xxx PMBus sequencers/managers work with analog and PMBus point-of-load voltage regulators to provide a PMBus management and voltage-regulation solution in multirail systems, which almost always have one or more high-current application-specific integrated circuits (ASICs), processors and/or field-programmable gate arrays (FPGAs).

The loads require precise multiphase step-down conversion from the 12V intermediate bus to their respective rails. Typical load currents range from 50A to 200A, and the multiphase converter may require up to six phases to distribute power and thermals effectively and reduce the size and count of the inductor and output capacitors through phase interleaving.

One such six-phase converter is the TPS53667.

How does a multirail UCD90xxx PMBus sequencer come together with multiple PMBus voltage regulators in a design? The TI Designs PMBus Power System for Enterprise Ethernet Switches Reference Design is a good example, as shown in Figure 3.

The design employs a PMBus sequencer, a PMBus hot-swap IC (for the input current) and eight analog and PMBus voltage regulators, including a four-phase PMBus buck controller and a double-data-rate (DDR) termination (Vtt) switcher. The Fusion Digital Power GUI provides a graphical representation of the power tree and offers the capability to program the main parameters on the top half, while monitoring key parameters such as voltage, current, temperature and power on the bottom half.

If you are designing multirail systems with high-current processors, ASICs and/or FPGAs and want to simplify your design and characterization, reduce development time, and increase your system's diagnostic capability, consider TI's PMBus power solutions.



	4) Texas Instruments	
	Monitor 12.029 V Aug ms 26 W 48.3%	m TPS53647 @ PMBus Address 100d
NO NA. NO ANA.	HCU EXT and Server 0.401 A Aug PLAT 13,249 W	Operation: O on @ Off
	SMEALERT# Asserted	Voet: 1.005 V VF PSF OFF
	ADA Nove - 4000 14002 3.0 MARCIN 2.012 V 3V Mon13	Rowt: 0.00 A COS HIM CVF ASICI
	1.317,546022 0.20 A	Temp: 41.4C (OCP (OTH) (Oth)
And the second se	Lance Lance Heat Heat	Clear Faults
	Raf #1 UCD90240 @ 119d	
The second se	1403 V 3.3V Mon20	TPS544C25 @ PMBus Address 18dTV Mont
	To dat - Real Life V Real 13.4 Register	Operation: Oon @0#
	A DV OVT	Voet: 3.008 V (set) (no (ore)
ALC LE .	Low come where Levy more but a Chiefe Chiefe The Low Law Law Annual Law Annual Law Law Annual Law A	Bout: 0.63.A. Cos. HIR Cost ASIC2
STATE OFFICE	IV.007 - North Lift V World 647 4	Temp: 25 % Ocr (pre) ore
Statistic sector budden	0.659 .007 Mun <sup>2</sup> 1.544 V mul3 0.54 Chear Faults	VOVE CHO 1.012 V Onar Faults
	VCON Routh & SAT V Routh & SAT A	
THE REPORT OF A REAL PROPERTY AND A REAL PROPERTY A REAL PROPERTY A REAL PROPERTY A REAL PROPERTY AND A REAL PROPERTY	17553515	In TPS544C25 @ PMBus Address 36d 0.83V Mon7
	(00) (00) (00) (00) (00) (00) (00) (00)	Operation: Oor @off
田田,田田,田田,田田,	Then the Then the Sec. (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	Vout: 1.045 V 240/7 200 OFF
	0001 0000 0000 00000 00000 00000 00000 00000	Bowt: 0.56 A CM. MR CMF - ASIGN
Caro.	en 1 Leo	Temp: 23 % OOF OTHE OTH
	Click to auto-run Adjustable Vout	VOUT CHO LOAS V Char Faults
224 425	AirS Internal 10,000 (meec)	
Linguese Contraction of the line of the li	UCD90240 @ 119 Select Rots	Select Plots TPS544C25 @ 36 Select Plots
0.0	West - Rad #1 * West - Output Wilkage * West - Output Wilkage	Visit - Oxford Visitage
and distant and	14.00 L20 L20 L40 L	Nort - Output Voltage
	1200 1.40	1.40
	10.00 L002 V 1.20	1.39
	8.00	1.00 L045 V
	4.00	0.40
	140	8.60
	2.00 6.20	9,40
	LASS V	0.00
	0.00 0.00	0.00 58.40 59.00 59.40

Figure 3. The Reference Design's PMBus Board and Fusion Digital Power GUI

## **Additional Resources**

- Watch the video, "Unboxing a 24-A, 6-Phase PMBus Buck Converter Design."
- See the digital power supply portal for more information about TI PMBus power solutions.

## IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2023, Texas Instruments Incorporated