

Beyond the limit: How smart audio amplifiers dynamically boost microspeaker sound

Supriyo Palit

Systems engineer, consumer audio amplifiers and haptics

Aditya Sundar

Systems engineer, consumer audio amplifiers and haptics

Introduction

Delivering loud, immersive sound from thin, lightweight devices is challenging because microspeakers face strict loudness ceilings. To prevent blown voice coils or torn diaphragms caused by high voltage, designers traditionally cap peak volume well below a speaker's rated power, restricting achievable sound pressure level (SPL). This limitation also affects larger speakers in Bluetooth devices and soundbars. Smart audio amplifiers address this by fusing a high-precision IV-sense analog-to-digital-converter (ADC) front end with real-time DSP and protection algorithms. By intelligently overdriving speakers for short durations within a safe zone, a smart amplifier allows hardware to reach its true physical limits, delivering 8dB to 10dB higher perceived loudness and deeper bass.

The physics of microspeaker vulnerability

A standard microspeaker consists of a voice coil suspended in a magnetic field, attached to a diaphragm (or cone) and held in place by a suspension system. When an electrical signal passes through the coil, it creates an electromagnetic force that moves the cone, vibrating the air to create sound. See [Figure 1](#).




Figure 1. Microspeaker construction

When engineers increase audio output in these tiny components to produce louder sound, they encounter two catastrophic failure mechanisms: thermal overload and mechanical over-excursion.

From a thermal perspective, loudspeakers are highly inefficient, where 95% to 99% of input electrical energy becomes heat rather than sound. Thus, continuous high-voltage signals can push the voice coil past its rated temperature ($T_{\max}$), melting the wire insulation and causing electrical shorts. Mechanically, producing bass at high volumes requires large cone excursion; if the drive voltage pushes the cone past its physical travel limit ($X_{\max}$), the suspension can stretch beyond its elastic limit, letting the voice coil strike the magnet's backplate (bottoming out) or tearing the diaphragm from its surround and causing distortion, buzzing or total acoustic failure.

Traditional versus smart approaches to audio design

In a traditional audio design, engineers cap the peak audio power at the speaker's continuous rated power to ensure safety. This static voltage ceiling forces the entire signal down to a defensive floor, resulting in low volume and weak bass.

A smart amplifier constantly monitors the state of the speaker and adapts its output in real time. By understanding exactly how hot the voice coil is, and exactly how far the diaphragm is moving at any given millisecond, a smart amplifier can safely drive speakers with high-voltage peaks that would instantly destroy it under a traditional system.

A smart amplifier algorithm dynamically modulates loudness, allowing for 8dB to 10dB higher peak loudness SPL by ensuring that the speaker's estimated excursion stays within $X_{\max}$ and that its estimated voice coil temperature stays within $T_{\max}$. The algorithm only pulls back the energy when the speaker actively approaches a literal breaking point. See **Figure 2**.




Figure 2. Smart amplifier system architecture

Specialized sensing hardware, together with an acoustic software model running on the DSP, form a real-time feedback loop that enables the amplifier to adapt its output on the fly.

Integrated IV-sense circuitry

Smart amplifiers utilize current and voltage (IV)-sense circuitry. After integrated analog-to-digital converters (ADCs) capture the exact voltage applied to the speaker and the exact current drawn by it, the system computes the speaker's electrical impedance ($Z = V / I$) in real time. Dynamic impedance changes – driven by temperature and mechanical movement – provide the raw sensory input for protection algorithms.

The ADC's conversion range is set to ensure that it is possible to sense the full-scale audio signal played through the amplifier. High-precision hardware ensures maximum utilization of the speaker's loudness. Any current or voltage sensing

error is a direct hit to loudness, since the speaker protection algorithm would need that much additional error guard banding to never breach the $X_{\max}$ and $T_{\max}$ limits.

A typical $\pm 0.35\%$ error results in $\pm 1^\circ\text{C}$ error in the voice coil temperature estimation through IV sensing. TI's **TAS2781**, **TAS2783**, and **TAS2573** ADCs achieve high accuracy in IV sensing, resulting in minimal guard-band requirements for temperature and excursion. A high signal-to-noise ratio (SNR) and dynamic range (DNR) avoid sensing errors and reproduce the audio content through the speaker with high fidelity. See **Figure 3**.




Figure 3. The co-working of hardware and software in a smart amplifier

The VSNSP and VSNSM pins of the device sense the voltage across the speaker. These are sense lines that must be connected as close to the speaker terminal as possible to ensure accurate measurement.

Since the voltage across the speaker in a Class-D amplifier is a high-voltage switching node, the IV-sense ADCs require a high common-mode rejection ratio analog front-end circuit to extract the audio content from the switching voltage and to convert the high voltage to a lower voltage for precision sensing. Sigma-delta or successive approximation register ADC circuitry senses this low-voltage audio content to extract precise IV information. The ADC output is typically at a much higher frequency, such as 3MHz, since the data ADC is oversampled to achieve high SNR and DNR. The ADC output data is decimated down to the audio rate (48KSPS) and high pass-filtered to remove the DC content (if any), before being used by the SmartAmp algorithm running in the integrated DSP of the TAS2781, TAS2783, or TAS2573.

Phase-matching the I and V audio channels to high precision – within $\pm 1\mu\text{s}$ – enables highly precise real-time estimation of the speaker impedance. The IV-sense data can also be monitored by the user and brought out on TDM SDOUT pins or through the Soundwire data interface.

The DSP is the brain of a smart amplifier. It hosts the speaker protection algorithms, running complex mathematical models of the loudspeaker alongside real-time predictive filters. The DSP acts as a gatekeeper, modifying the incoming digital audio stream on the fly based on the telemetry provided by the IV-sense hardware.

For a smart amplifier to work, it must be calibrated to the specific loudspeaker it is driving. Audio engineers use specialized diagnostic tools to characterize the target microspeaker in an acoustic chamber. They measure its thermal resistance (R_E), resonance frequency (f_0), mechanical damping (Q_{ms}) and magnetic strength (BI). Programming these parameters into the DSP serves as a model for the speaker to create a customized safety envelope. TI's PurePath™ Console 3 audio toolkit provides calibration, modelling, and end-system tuning support.

The temperature protection algorithm

Thermal protection in a smart amplifier relies on the physical law that the electrical resistance of a metal conductor changes predictably with temperature. This is known as the temperature coefficient of resistance (α).

As a voice coil heats up, its R_E increases linearly, and the smart amplifier's IV-sense hardware isolates this resistance from the measured impedance. **Equation 1** solves for the coil's internal temperature:

$$R_{dc}(T) = R_E(T_0)[1 + \alpha(T - T_0)] \quad (1)$$

where $R_E(T)$ is the measured resistance at current time T , $R_E(T_0)$ is the baseline resistance from factory calibration, and α is the coil material's temperature coefficient of resistance (such as copper).

This eliminates the need for bulky, slow-responding physical thermistors.

This measurement is invoked only periodically – a checkpoint reading rather than a continuous stream – for two reasons: it is less trustworthy at low output levels or during low-to-high power transitions (noise-limited signals, settling error and offsets), and running the sense ADC and its analog front end continuously would consume unnecessary power, especially in battery-powered, low-volume listening.

Thermal modeling and control

Because the R_E measurement only arrives periodically, the algorithm needs a way to know the voice coil's temperature continuously, in the gaps between measurements. The solution is a predictive thermal model – a multistage resistor-capacitor thermal network (see **Figure 4**). This model simulates heat transfer from the voice coil to the speaker magnet structure, and finally to the device's chassis and ambient air, and it runs at the full control-loop rate. Each time a new, IV-sense-based R_E reading arrives, re-anchors the model, and corrects any drift accumulated since the last checkpoint.




Figure 4. Loudspeaker predictive thermal model

By tracking heat dissipation paths in this way, the algorithm can predict how fast the temperature will rise during an upcoming audio peak and how quickly it will cool down during a pause. This estimate feeds a power controller that enforces the safe operating limit of the audio signal continuously and without interruption. As the estimated voice coil temperature approaches the T_{max} of the loudspeaker, the controller reduces the permissible limit to protect the loudspeaker from overheating. When the loudspeaker cools down during soft audio segments, the controller will allow higher-power delivery to the loudspeaker.

The thermal protection algorithm controls the audio signal based on the power limit predicted by the thermal controller, applying a smooth, broadband gain reduction that lowers the overall root-mean-square (RMS) power delivered to the speaker so that the voice coil can cool down without abrupt, audible drops in volume. This gain reduction uses slow attack and release times; because human hearing is less sensitive to gradual changes in overall volume, the attenuation blends seamlessly into the background, preserving the perceived dynamics of the audio. See [Figure 5](#).




Figure 5. Closed-loop temperature protection

In [Figure 6](#), the blue curve represents the smart amplifier’s estimated temperature, while the red line indicates the T_{max} limit. The amplifier dynamically modulates the audio to ensure that the speaker is always within reliable temperature limits (leaving some headroom for IV-sensing errors).




Figure 6. Smart amplifier temperature estimation vs the T_{max} limit

The excursion protection algorithm

Unlike thermal protection, which deals with slow-moving thermal masses and RMS power, excursion protection is highly volatile. A speaker cone can travel from rest to maximum over excursion within a single waveform cycle in a fraction of a millisecond.

Because putting a physical laser displacement sensor inside a smartphone to track speaker cone movement is impossible, the smart amplifier relies on a mathematical simulation of the speaker mechanics. This is based on Thiele-Small parameters and linear state-space models of the transducer. See [Figure 7](#) and [Table 1](#).




Figure 7. Electromotive model of a loudspeaker

Electromotive parameter	Description
R _{ms}	Mechanical damping factor
M _{ms}	Mechanical mass
C _{ms}	Mechanical compliance
Bl	Force factor
R _E	DC resistance of the voice coil
L _E	Inductance of the voice coil
u	Amplifier voltage
i	Voice coil current
v	Velocity of membrane
F	Mechanical force in magnetic field
x	Magnetic excursion

Table 1. Main parameters in a speaker electromotive model

The algorithm uses real-time current and voltage data to calculate the back-electromotive force (back-EMF) generated by the speaker's movement. After combining back-EMF data with the “digital twin” speaker model, the DSP runs an observer loop such as a normalized least mean square filter to update the model in real time. The speaker model is used to calculate the instantaneous physical displacement (x) of the cone using an excursion predictor voltage-to-excursion filter ([Equation 2](#)):

$$Z_{exc} \left(s \right) = \frac{X(s)}{V(s)} = \frac{Bl}{M_{ms}R_E} \times \frac{1}{s^2 + s \times \left(\frac{R_{ms} + \frac{Bl^2}{R_E}}{M_{ms}} + \frac{1}{M_{ms}C_{ms}} \right)}$$

(2)

Look-ahead limiter

If a low-frequency bass transient (such as a snare drum hit or an explosion in a movie) threatens to push the cone past its $X_{\max}$, the excursion protection algorithm deploys rapid, targeted countermeasures. A brief digital delay buffer (typically a few milliseconds) enables the DSP to see a dangerous peak before it actually reaches the amplifier stage, giving the algorithm time to apply a precise, instantaneous peak attenuation to that specific waveform cycle. See [Figure 8](#).




Figure 8. Closed-loop excursion protection

In [Figure 9](#), the blue curve represents the smart amplifier's estimated excursion, while the red lines indicate the $X_{\max}$ limits. The amplifier dynamically modulates the audio to ensure that the speaker is always within reliable excursion limits.




Figure 9. Real-time excursion tracking relative to the $X_{\max}$ limits

Integrating the audio tuning chain

Unlike conventional audio designs that use the equalizer (EQ) and dynamic range compressors (DRCs) as aggressive limiting tools to ensure safety of the microspeaker, the smart amplifier paradigm enables true artistic tuning of the audio signal chain. For example, tuning engineers can use the parametric EQ to aggressively boost low frequencies (bass extension) and make tiny smartphone speakers sound like a much larger acoustic enclosure. The EQ can also flatten response peaks to optimize vocal clarity.

A smart amplifier also uses multiband DRCs aligned with its protection models, splitting the audio into distinct low, mid, and high bands. Designers can optimize the mid and high bands for maximum perceived loudness, crisp dialogue and wide spatial imaging. The low band is tightly coupled with the excursion model in order to provide the optimum bass response based on the actual physical displacement of the cone.

Smart amplifiers enhance loudness and frequency response by safely maximizing speaker output, providing advantages in hardware performance, design, and reliability. Specific benefits include:

- **Extended low-frequency response:** Instead of rolling off bass permanently with a static hardware filter, smart amplifiers use an intelligent, sliding bass extension strategy. At low volumes, the bass extends deep into lower frequencies. As the volume increases, the look-ahead limiter activates only as much as needed to prevent over-excursion, retaining maximum possible bass presence across all volume levels.
- **Component optimization and space savings:** Because software handles protection, product designers can source smaller, thinner speaker modules, freeing up space inside tight device enclosures for larger batteries, advanced camera sensors, or slimmer product profiles.
- **Near-zero field return rates:** By acting as a reliable digital shield against scorched voice coils and torn diaphragms, smart amplifiers drastically reduce hardware failures and save millions in warranty support costs and field return claims.

Figure 10 shows a comparison of loudness and frequency response, comparing smart amplifiers versus traditional amplifiers.




Figure 10. Comparison of loudness and frequency response of smart amplifiers vs traditional non-smart amplifiers

Conclusion

By replacing passive safety margins with active, hardware-software co-driven surveillance, smart amplifiers bridge the gap between fragile microacoustics and consumer demand for powerful, high-fidelity sound. Through real-time current and voltage sensing, nonlinear thermal and mechanical modeling, and audio engineering, these systems successfully push microspeakers to their absolute physical boundaries. The result is a generation of smartphones, laptops, and smart home devices that sound remarkably loud, rich, and full, all while maintaining component reliability.

About the authors

Aditya Sundar, a systems engineer for consumer audio amplifiers and haptics products, has worked at Texas Instruments for more than 11 years. He previously served as an analog design manager. Sundar holds a bachelor's degree in electronics and instrumentation engineering from the Birla Institute of Technology & Science, Goa. He specializes in mixed-signal Class-D audio signal chain design and works extensively on mixed-signal boosted Class-D audio amplifiers, piezo drivers and loudspeaker protection technology.

Supriyo Palit is a systems engineer for consumer audio amplifiers and haptics products at Texas Instruments, where he has spent more than 27 of his 30 years in the industry. He holds a postgraduate degree in electrical communications from the Indian Institute of Science in Bangalore. His work focuses on audio signal processing, loudspeaker protection technology, audio power management, haptics and voice algorithms.

Acknowledgments

The authors would like to acknowledge Vallabha Hampiholi, Nilendra Gadre, Michael Kim, Jasjot Chadha, and Mashkurahmed Badebade for their technical contributions during the development of this article.

Additional resources

- Check out this [smart amplifiers presentation from CES 2015](#).
- Read the application reports, “[Smart Amp Tuning Guide](#),” “[Smart Amp Quick Start Guide](#)” and “[Getting Started with Smart Amp Development](#).”

Important Notice: The products and services of Texas Instruments Incorporated and its subsidiaries described herein are sold subject to TI's standard terms and conditions of sale. Customers are advised to obtain the most current and complete information about TI products and services before placing orders. TI assumes no liability for applications assistance, customer's applications or product designs, software performance, or infringement of patents. The publication of information regarding any other company's products or services does not constitute TI's approval, warranty or endorsement thereof.

PurePath™ is a trademark of Texas Instruments.
All trademarks are the property of their respective owners.

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you fully indemnify TI and its representatives against any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](#), [TI's General Quality Guidelines](#), or other applicable terms available either on [ti.com](#) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products. Unless TI explicitly designates a product as custom or customer-specified, TI products are standard, catalog, general purpose devices.

TI objects to and rejects any additional or different terms you may propose.

Copyright © 2026, Texas Instruments Incorporated

Last updated 10/2025