

# **Programming PLL Controllers on OMAP-L1x8/C674x/AM18xx**

---

---

---

*Catalog Processors*

## **ABSTRACT**

This document discusses the internal clocking architecture of Texas Instruments OMAPL1x/C674x/AM1x family using a provided clocking spreadsheet. The spreadsheet also provides guidance on max frequency supported by the PLL(s) and its SYSCCLKs for a given operating point. This document applies to the following devices: OMAPL138, OMAPL132, C6748/46/42 and AM18x family.

The OMAP-L138, C6748/46/42 and AM18x family have similar internal clocking architecture. For more details on the differences between these devices, see the device-specific data manual.

The spreadsheet discussed in this document can be downloaded from the following URL: <http://www.ti.com/lit/zip/spracm2>.

---

## **Contents**

1	Introduction .....	1
2	Clocking Check Spreadsheet .....	1

## **Trademarks**

All trademarks are the property of their respective owners.

### **1 Introduction**

There are two PLL controllers on the OMAP-L1x8, C674x, and AM18xx devices. Each PLL controller has multiple output clocks and several configurations. The clock outputs of the PLL controllers are used to clock different parts of the device including the ARM, DSP, DDR2 controller, and device peripherals. Furthermore, each input and output clock has a frequency min and max that must be observed. Some of these frequency limits change with the operating voltage of the device.

### **2 Clocking Check Spreadsheet**

The [clocking check spreadsheet](#) was created such that you can quickly check for frequency violations. The spreadsheet was created based on the PLL controller information in the OMAP-L138, C6748, AM1808 device-specific data manual (see [Figure 1](#)). You can enter several values including PLL multipliers and system clock dividers. The spreadsheet flags any timing violations. The operating core voltage of the device can also be specified. The spreadsheet adjusts the frequency limits based on the operating voltage.




Figure 1. PLL Controller

## IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale ([www.ti.com/legal/termsofsale.html](http://www.ti.com/legal/termsofsale.html)) or other applicable terms available either on [ti.com](http://ti.com) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2019, Texas Instruments Incorporated