



VBUS Settings	
J2	5V External
Shunt ON	5V to VBUS
Shunt OFF	No 5V to VBUS
J3	PORT A VBUS
Shunt ON	5V -> VBUS - Host Mode (self powered)
Shunt OFF	5V < VBUS - Device Mode (Bus powered)
Shunt OFF	5V NC VBUS - Device Mode (NC)
J10	PORT B VBUS
Shunt ON	5V -> VBUS - Host Mode (self powered)
Shunt OFF	5V < VBUS - Device Mode (Bus powered)
Shunt OFF	5V NC VBUS - Device Mode (NC)

