

Port Pin P1.1:  
High = RF1 = Internal Antenna  
Low = RF2 = External Antenna

