### CC110x/CC111x OOK/ASK Register Settings

By Sverre Hellan

### Keywords

- OOK
- ASK
- PER (Packet Error Rate)
- CC1100
- CC1100E

- CC1101
- CC1110
- CC1111
- CC430

#### 1 Introduction

This design note provides guidelines for finding optimum register settings for OOK/ASK operation. The starting point for the optimization is the preferred settings given by the SmartRF® Studio SW. The user needs to measure the sensitivity (PER) over the full input dynamic range to determine the optimum settings.

This design note uses CC1101 as an example on how to find optimum register settings, but it is also applicable for CC1100, CC1100E, CC1110, CC1111, and CC430.



SWRA215E Page 1 of 8

### **Table of Contents**

Κ	EYW	VORDS	1
1		INTRODUCTION	1
2		ABBREVIATIONS	2
3		OOK/ASK REGISTER SETTINGS	3
	3.1	AGC SETTINGS	3
		IF FREQUENCY	
	3.3	PROCEDURE FOR FINDING OOK/ASK SETTINGS USING SMARTRF® STUDIO	5
4		GENERAL INFORMATION	8
	41	DOCUMENT HISTORY	R

### 2 Abbreviations

AGC Automatic Gain Control
ASK Amplitude Shift Keying
EM Evaluation Module
2-FSK Frequency Shift Keying

GFSK Gaussian shaped Frequency Shift Keying

IF Intermediate Frequency
MSK Minimum Shift Keying
OOK On-Off Keying
PER Packet Error Rate

SW Software



SWRA215E Page 2 of 8

### 3 OOK/ASK Register Settings

### 3.1 AGC Settings

The register settings provided by SmartRF<sup>®</sup> Studio have been optimized for 2-FSK/GFSK/MSK modulation and when using one of the preferred settings and only changing the modulation format to OOK/ASK, the AGC settings might result in unstable or non-optimum reception (i.e. degraded sensitivity). This is pictured in Figure 1.




Figure 1. Example of Unstable, Non-Optimum, and Optimum Reception

The optimum AGC settings change with RX filter bandwidth and data rate, but for OOK/ASK the following has been found to give good results:

AGCCTRL2 = 0x03 to 0x07 AGCCTRL1 = 0x00 AGCCTRL0 = 0x91 or 0x92

In the example shown in Figure 2, the best sensitivity is achieved with AGCCTRL2 = 0x04, AGCCTRL1 = 0x00, and AGCCTRL0 = 0x92. Please note that optimum register settings change with data rate so it is important to measure sensitivity for different combinations of AGCCTRL2 and AGCCTRL0. Furthermore, as shown in Figure 1, some combinations of AGC settings results in unstable reception. That is, for some input power levels above the sensitivity limit there will be degraded packet error rate (PER). It is therefore important to check the PER for the entire dynamic range and not only at the sensitivity limit. One option is to check the PER for every 2 dB increase in input power level.

AGCCTRL2.MAGN\_TARGET[2:0] is used to set an on-chip target value for the peak signal amplitude. MAGN\_TARGET is used by the AGC loop to set the correct gain.

AGCCTRL0.FILTER\_LENGTH[1:0] is used to configure the ASK decision boundary. If the ASK decision boundary is set to 8 dB, the "low" bit must be at least 16 dB below the "high" bit.



SWRA215E Page 3 of 8





Figure 2. PER versus Input Power Level for Different AGC Register Settings (3.8 kBaud, 100 kHz RX Filter Bandwidth)

#### 3.2 IF Frequency

Register FSCTRL1 sets the IF frequency and the optimum value is different for different RX filter bandwidths. It is therefore recommended to find the FSCTRL1 setting using one of the preferred RX filter bandwidth settings in SmartRF<sup>®</sup> Studio (see Figure 3). If the wanted RX filter bandwidth is not given by one of the preferred settings, choose the FSCTRL1 setting for the first RX filter bandwidth that is wider than the wanted RX filter bandwidth.

As an example, for a wanted 150 kHz RX filter bandwidth use the FSCTRL1 setting given for 232 kHz RX filter bandwidth.



RX filter bandwidths used by preferred settings: 58 kHz, 100 kHz, 232 kHz, 325 kHz, 540 kHz, 812 kHz

Figure 3. Available RX Filter Bandwidths Given by the Preferred Settings in SmartRF® Studio



SWRA215E Page 4 of 8

Note that the FREND1, FIFOTHR, TEST2, and TEST1 register settings change for different RX filter bandwidths.

#### FREND1:

- RX filter bandwidth > 101 kHz, FREND1 = 0xB6
- RX filter bandwidth ≤ 101 kHz, FREND1 = 0x56

#### TEST2:

- RX filter bandwidth > 325 kHz, TEST2 = 0x88
- RX filter bandwidth ≤ 325 kHz, TEST2 = 0x81

#### TEST1:

- RX filter bandwidth > 325 kHz, TEST1 = 0x31
- RX filter bandwidth ≤ 325 kHz, TEST1 = 0x35


#### FIFOTHR:

- RX filter bandwidth > 325 kHz, FIFOTHR = 0x07
- RX filter bandwidth ≤ 325 kHz, FIFOTHR = 0x47

### 3.3 Procedure for Finding OOK/ASK Settings using SmartRF® Studio

As an example, assume 4.8 kBaud data rate and 203 kHz RX filter bandwidth.


1) Use SmartRF® Studio to find the optimum IF frequency. Select the preferred setting that has an RX filter bandwidth equal to the wanted bandwidth. If the wanted RX filter bandwidth is not given by one of the preferred settings, chose the first RX filter bandwidth that is wider than the wanted bandwidth. For a 203 kHz wanted RX filter bandwidth, select the 232 kHz RX filter bandwidth for optimum IF frequency.





SWRA215E Page 5 of 8


2) Change the data rate and the RX filter bandwidth to the wanted values. Change the modulation format to ASK/OOK. Press "Reset CC1101 and write settings" (if SmartRF® Studio is being used to control a CC1101EM) and then "Copy settings to Register View"





SWRA215E Page 6 of 8


3) In Register View, change the AGCCTRL2, AGCCTRL1, and AGCCTRL0 settings as explained in Section 3.1. Make sure the FSCTRL1, FIFOTHR, FREND1, TEST2, and TEST1 registers are set as explained in Section 3.2. It is possible to print the register settings to a file using "Export CC1101 Registers" under "File". Press the "Write" button for the register to be updated if SmartRF® Studio is being used to control a CC1101EM.





SWRA215E Page 7 of 8

4) If SmartRF<sup>®</sup> Studio is being used to perform the test, go back to Normal View. Check the Manual Init box for the changes done in Register View to take effect.



#### 4 General Information

#### 4.1 Document History

Revision	Date	Description/Changes
SWRA215E	2012-03-08	Changed document name from "CC11xx OOK/ASK Register Settings" to "CC110x/CC111x OOK/ASK Register Settings"
SWRA215D 2012-02-10 C		Corrected error in RX BW on page 5
SWRA215C 2012-02-09		Added FIFOTHR to the list of registers on page 5
SWRA215B	2009-11-11	Added CC430 to list of devices
SWRA215A	2009-03-15	Added CC1100E. Added info about TEST2, TEST1, and FREND1 register settings for wide RX filter bandwidths.
SWRA215	2008-06-09	Initial release



SWRA215E Page 8 of 8

#### **IMPORTANT NOTICE**

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

**Applications** 

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Audio	www.ti.com/audio	Automotive and Transportation	www.ti.com/automotive
Amplifiers	amplifier.ti.com	Communications and Telecom	www.ti.com/communications
Data Converters	dataconverter.ti.com	Computers and Peripherals	www.ti.com/computers
DLP® Products	www.dlp.com	Consumer Electronics	www.ti.com/consumer-apps
DSP	dsp.ti.com	Energy and Lighting	www.ti.com/energy
Clocks and Timers	www.ti.com/clocks	Industrial	www.ti.com/industrial
Interface	interface.ti.com	Medical	www.ti.com/medical
Logic	logic.ti.com	Security	www.ti.com/security
Power Mgmt	power.ti.com	Space, Avionics and Defense	www.ti.com/space-avionics-defense
Microcontrollers	microcontroller.ti.com	Video and Imaging	www.ti.com/video

RFID <u>www.ti-rfid.com</u>
OMAP Mobile Processors www.ti.com/omap

**Products** 

Wireless Connectivity www.ti.com/wirelessconnectivity

TI E2E Community Home Page

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2012. Texas Instruments Incorporated

e2e.ti.com