

ABSTRACT

The AM13E230x Bootloader (referred to as BSL) provides a method to program and verify the device memory (Flash) through multiple serial interfaces including UART, I2C, and MCAN.

Table of Contents

1 Introduction	2
1.1 Overview of BSL Features.....	2
1.2 Terminology.....	2
1.3 Additional Resources.....	2
2 BSL Architecture	3
2.1 Design.....	3
2.2 BSL Invocation.....	4
2.3 Memory.....	5
2.4 BSL NONMAIN Configuration.....	6
2.5 Changing BSL Configuration.....	13
3 Bootloader Protocol	15
3.1 Packet Format.....	15
3.2 BSL Protocol.....	15
3.3 Bootloader Core Commands.....	16
3.4 Bootloader Core Response.....	24
3.5 Bootloader Security.....	27
4 Sample Program Flow with Bootloader	28
5 Revision History	30

Trademarks

All trademarks are the property of their respective owners.

1 Introduction

1.1 Overview of BSL Features

The Bootstrap Loader (BSL) provides a method to program or verify the device flash memory through a standard UART, I2C, or MCAN serial interface.

Note

Not all UART, I2C, or MCAN configurable pins can be used to program the device flash memory. See the [Section 2.4.2](#) section for more information.

Key features of the BSL that are accessible through the serial interface include:

- Programming and erasing flash memory
- Can return a 32-bit CRC of a code or data region (2KB minimum region size) to verify programming
- Can enable code or data read-out (disabled by default)
- Can return a firmware version number via a pointer to the MAIN flash
- Can specify a hardware invoke GPIO
- Access is always protected with a 256-bit password
- Configurable security alert handling for resisting brute force attacks
- ROM-based interface plugins for UART, I2C, and MCAN with auto-detection capability
- UART baud rate configuration with multiple options
- Configurable interface pins for UART, I2C, and MCAN
- Can use a custom bootloader

1.2 Terminology

Bootstrap Loader (BSL) - Boot routine used to load data to the device memory

Bootcode (BCR) - Startup routine that runs after BOOTRST to configure the device for application execution

BCR configuration - Configuration structure that contains all user configurable parameters for boot code, residing in NONMAIN flash memory

BSL configuration - Configuration structure that contains all user configurable parameters for Bootloader, residing in NONMAIN flash memory

1.3 Additional Resources

- AM13E230x Technical Reference Manual
- AM13E230x Microcontrollers Data Sheet
- AM13E230x MCU Software Development Kit (SDK)

2 BSL Architecture

2.1 Design

The bootloader will be invoked by the BCR when a valid bootloader invocation condition is detected. It will be invoked only if the bootloader is enabled in the BSL mode field of the BCR configuration.

Once the bootloader is started, it first executes the "Init" phase where the initial checks of the BSL configuration are done and the device is configured for bootloader operations.

Next, the bootloader enters the "Interface Autodetection" phase. In this phase, the BSL configures all the available BSL ROM interfaces (UART/I2C/MCAN), if registered. The BSL then polls for the data through all the interfaces one by one. When a valid [connection packet](#) is received in one of the interfaces, that interface will be considered as active for further communication and the other interfaces will be disabled. Interface discovery is polled for 10 seconds. If no interface has been detected, the device is put in STANDBY mode.

After interface detection, the BSL enters the "Command Reception" phase. In this phase the BSL will be waiting in an infinite loop for commands from the host. When a valid command is received, the command is processed and the response from the BSL is sent back to the host. Then, it goes back to the loop and waits for the next command, and so on.

If the 'Start Application' command is received, the bootloader will trigger a system reset, after which the Bootcode is executed and the application is invoked. This phase also has a timeout of 10 seconds. If there is no valid command received, the bootloader is locked, and the device enters Sleep mode.




Figure 2-1. BSL Architecture

2.1.1 Timeout Feature

The bootloader will time out when no activity is detected and enters low-power mode to save power.

This has been implemented at the following two phases:

1. [Interface Autodetection](#)
2. [Command Reception](#)

2.1.1.1 Interface Autodetection

In the "Interface Detection" phase, if there is no valid connection command received for 10 seconds over any valid interface (UART/I2C/MCAN), the bootloader enters STANDBY mode.

A BOOTRST is required to exit this state and use the bootloader by creating the BSL invocation condition again.

2.1.1.2 Command Reception

In the "Command Reception" phase, if no valid command is received for 10 seconds the bootloader will enter SLEEP mode. To wake up the device from SLEEP mode, a data transaction should happen on the active interface.

The bootloader will be locked before entering Sleep mode to reduce the chance of a brute force attack. Hence, after waking up from the low power mode, the bootloader needs to be unlocked again by sending the 256 bit BSL Password (see [Unlock Bootloader command](#)).

2.2 BSL Invocation

Bootloaders shall be invoked only by the Bootcode; When any of the BSL invocation conditions are met and if the Bootloader is enabled in the BCR configuration.

When Fast Boot mode is enabled in the BCR configuration, the bootloader can be invoked only by a DSSM command and Application request. Other checks are skipped to save execution time.

Once the device transitions to **HS-SE (High Secure – Security Enforced)**, the bootloader is completely disabled and no BSL invocation is possible, ensuring maximum protection of customer code.

2.2.1 Application Request

To invoke the bootloader from an application, set the RESETLEVEL as BOOTLOADERENTRY and trigger reset through the RESETCMD register. This sequence causes a system reset, and the Bootcode is executed and the bootloader is invoked.

Because a system reset is issued, all the peripheral configurations are reset while exiting the application.

2.2.2 GPIO Based Invocation

Using a GPIO for BSL invocation can be configured in the BSL Configuration in NONMAIN flash. Fresh devices from the factory will have the TI programmed default pin in BSL configuration. On AM13E230x devices, the default pin, regardless of device package is **PA6** and is **active high**. For more details on configuring this pin, refer to [Section 2.4.3](#).

GPIO pin based invocation is enabled by default, but can be disabled in the BCR configuration. The selected GPIO should be asserted before POR, and the state should be maintained for at least T_start ms after POR. Then the GPIO pin state can be de-asserted.




Figure 2-2. Invocation From GPIO

* - GPIO pin to be used as 'BSL Invoke' and 'Expected Pin Level' can be configured in BSL configuration

** - T_{start} refers to the Cold boot startup time, specified in the device specific data sheet

Note

If GPIO-based BSL invocation is enabled, the configured GPIO pin should be either pulled high or low. **It should not be left floating**, which could cause unexpected BSL execution.

2.2.3 Debug Mailbox Command

When a debug interface is available, the "Invoke BSL" command can be sent through the Debug Subsystem Mailbox (DSSM).

For more details on the DSSM command usage, refer to the DSSM Commands section in the *AM13E230x Technical Reference Manual*.

2.2.4 Other BSL Invocation Methods

2.2.4.1 Pre-Boot Application Verification

If the application CRC verification is enabled in the BCR configuration, the Bootcode verifies the CRC for the given application memory range. If the CRC is incorrect, the bootloader is invoked. Note that the bootloader is invoked only if enabled. Otherwise, the Bootcode logs a catastrophic error and results in boot failure.

2.2.4.2 Blank Device Handling

When a blank device is detected (unprogrammed flash memory), the Bootcode does not automatically invoke the bootloader. Instead, it copies a while (1) loop to SRAM and waits for a debugger to be connected within 10 seconds. If no debugger connection is established within this timeframe, the device enters low power mode. This approach provides a more flexible development experience when working with blank devices.

2.3 Memory

2.3.1 SRAM Memory Usage

The AM13E230x BSL dynamically allocates SRAM memory based on the available SRAM size in the device. The SRAM memory layout contains the following two MAIN sections used for the bootloader's operation:

- **Data and Stack section** - Used by BSL for its operation. While exiting the bootloader, these sections of the SRAM are cleared.
- **Variable Buffer Space** - Buffer space used for storing the data packets received/sent during the BSL communication

The SRAM memory allocation structure is as follows:

1. BSL Buffer Start Address: Calculated as the end address of the SRAM data section used for BootROM operation, aligned to the next 8-byte boundary.
2. BSL Buffer End Address: Calculated as the RAM end address minus the stack size.
3. Available Buffer Space: The space between BSL Buffer Start Address and BSL Buffer End Address is divided into two equal parts:
 - a. RX Buffer: Used for receiving data packets, starts at BSL Buffer Start Address
 - b. TX Buffer: Used for transmitting data packets, starts at BSL Buffer Start Address + Buffer Size

The maximum buffer size is limited to 32KB (0x7FFF bytes) due to the BSL protocol reserving 2 bytes for defining length. Even though the AM13E230x has 128KB of SRAM, only 32KB will be used for each buffer (RX and TX).

The SRAM memory allowed for read and write access by the host is BSL Buffer Start Address to [SRAM end address – Stack Size], where SRAM end address is determined by the SRAM memory available in each device. Since the same SRAM space is shared with variable buffer space, it has chances of getting overwritten during an SRAM write/read operation.

2.4 BSL NONMAIN Configuration

The BSL Configuration in NONMAIN Flash memory (starting at address 0x60100800) allows specific parameters used by the BSL to be customized by the user.

2.4.1 BSL Configuration ID

The BSL_CONFIG_ID is a predetermined signature ID that identifies this as a Bootloader configuration structure. This 32-bit field serves as an identifier for the BSL configuration.

Usage: This field identifies the structure as a BSL configuration structure. It is a fixed value that should not be modified by users. The default value is 0x05000000.

Returned in Get Device Info: The BSL_CONFIG_ID is included in the response to the Get Device Info command (CMD_API_Get_Identity). This allows the host to identify the BSL configuration version or type.

2.4.2 BSL Interface Pins (BLINTERFACE_PINS)

The BLINTERFACE_PINS structure configures the physical pins and pin function multiplexer selections for the BSL communication interfaces (UART, I2C, or MCAN). This configuration allows the BSL to use specific pins for communication with the host.

UART Interface Pins (0x60101804)

Table 2-1. UART Interface Pin Configuration

NM1 Address	NM1 Address [31:24]	NM1 Address [23:16]	NM1 Address [15:8]	NM1 Address [7:0]
0x60101804	UART_TXD_PF[7:0]	UART_TXD_PAD[7:0]	UART_RXD_PF[7:0]	UART_RXD_PAD[7:0]

Note

ONLY pins with the UNICOMM4 (UC4) instance can be used for UART communication with the BSL.

Table 2-2. UART Interface Data Structure

Parameter	Type	Description	Default Value (Hex)	Device Implementation
UART_TXD_PF_mux_sel	uint8_t	Pad mux value for UC4 UART TX	0x07	MuxMode 7: UC4_TX_SDA_PICO
UART_TXD_pad_num	uint8_t	Physical pin number for UC4 UART TX	0x00	PA0
UART_RXD_PF_mux_sel	uint8_t	Pad mux value for UC4 UART RX	0x07	MuxMode 7: UC4_RX_SDA_PICO
UART_RXD_pad_num	uint8_t	Physical pin number for UC4 UART TX	0x01	PA1

I2C Interface Pins (0x60101808)

Table 2-3. I2C Interface Pin Configuration

NM1 Address	NM1 Address [31:24]	NM1 Address [23:16]	NM1 Address [15:8]	NM1 Address [7:0]
0x60101808	I2C_SCL_PF[7:0]	I2C_SCL_PAD[7:0]	I2C_SDA_PF[7:0]	I2C_SDA_PAD[7:0]

Note

ONLY pins with the UNICOMM2 (UC2) instance can be used for I2C communication with the BSL.

Table 2-4. I2C Interface Data Structure

Parameter	Type	Description	Default Value (Hex)	Device Implementation
I2C_SCL_PF_mux_sel	uint8_t	Pad mux value for UC2 I2C SCL	0x04	MuxMode 4: UC2_RX_SCL
I2C_SCL_pad_num	uint8_t	Physical pin number for UC2 I2C SCL	0x17	PA23
I2C_SDA_PF_mux_sel	uint8_t	Pad mux value for UC2 I2C SDA	0x04	MuxMode 4: UC2_TX_SDA
I2C_SDA_pad_num	uint8_t	Physical pin number for UC2 I2C SDA	0x16	PA22

MCAN Interface Pins (0x6010180C)

Table 2-5. MCAN Interface Pin Configuration

NM1 Address	NM1 Address [31:24]	NM1 Address [23:16]	NM1 Address [15:8]	NM1 Address [7:0]
0x6010180C	CAN_TXD_PF[7:0]	CAN_TXD_PAD[7:0]	CAN_RXD_PF[7:0]	CAN_RXD_PAD[7:0]

Note

ONLY pins with the MCAN0 instance can be used for I2C communication with the BSL.

Table 2-6. MCAN Interface Data Structure

Parameter	Type	Description	Default Value (Hex)	Device Implementation
MCAN_TX_PF_mux_sel	uint8_t	Pad mux value for MCAN0 TX	0x0A	MuxMode 10: MCAN0_TX
MCAN_TX_pad_num	uint8_t	Physical pin number for MCAN0 TX	0x0C	PA12
MCAN_RX_PF_mux_sel	uint8_t	Pad mux value for MCAN0 RX	0x0A	MuxMode 10: MCAN0_RX
MCAN_RX_pad_num	uint8_t	Physical pin number for MCAN0 RX	0x0B	PA11

2.4.3 BSL Invoke Pin Configuration (BSLPIN_INVOKE)

The BSLPIN_INVOKE structure configures the GPIO pin used to trigger BSL invocation. This allows the BSL to be invoked by setting a specific pin to a specific state during device startup.

BSL INVOKE GPIO Pin (0x60101810)

Table 2-7. BSL INVOKE Pin Configuration

NM1 Address	NM1 Address [15]	NM1 Address [14:8]	NM1 Address[7]	NM1 Address [6:5]	NM1 Address [4:0]
0x60101810	BSLPIN_INVOKE_EXPECTED_PIN_STATE	BSLPIN_INVOKE_PAD_NUM	Reserved	BSLPIN_INVOKE_PORT_INDEX	BSLPIN_INVOKE_PIN_NUM

Table 2-8. BSL INVOKE GPIO Data Structure

Parameter	Type	Description	Default Value	Device Implementation
Pin_data_0 EXPECTED_PIN_STATE[7] PAD_NUM[6:0]	uint8_t	EXPECTED_PIN_STATE: Specifies the pin level that triggers BSL invocation. <ul style="list-style-type: none"> 0: BSL invoked when GPIO is LOW 1: BSL invoked when GPIO is HIGH PAD_NUM: Physical pin number	Pin_data_0 = 0x86 EXPECTED_PIN_STATE = 0x1 - BSL invoked when GPIO is HIGH PAD_NUM = 0x06 - PA6	BSL invoked when PA6 is HIGH
Pin_data_1 Reserved[7] PORT_INDEX[6:5] PIN_NUM[4:0]	uint8_t	PORT_INDEX: Specifies which GPIO port <ul style="list-style-type: none"> 0: GPIO port A (PAX) GPIO port B (PBx) GPIO port C (PCx) GPIO port D (PDx) 	Pin_data_1 = 0x06 PORT_INDEX[6:5] = 0x0 - GPIO port A (PAX) PIN_NUM[4:0] = 0x6 - IO number 6 on GPIO port A	PA6

The BSL invoke pin configuration allows the device to enter BSL mode when a specific GPIO pin is set to a specific state during device startup. By default, the BSL is invoked when Pin 6 of Port A (PA6) is set to HIGH during device startup.

To invoke the BSL using the configured pin:

1. Set the specified pin (default: Pin 6 of Port A) to the specified state (default: HIGH)
2. Power on the device or perform a reset
3. Maintain the pin state for at least T_start milliseconds after power-on reset
4. The pin state can be de-asserted after T_start milliseconds

Note

If pin-based BSL invocation is enabled, the configured GPIO pin must be pulled either high or low using a 10kΩ resistor depending on the configuration. Leaving the assigned BSL INVOKE GPIO floating could cause unexpected BSL execution.

2.4.4 Memory Readout Configuration

The READOUT field controls whether the BSL allows memory readout operations. When enabled, the Memory Read Back command can be used to read the contents of flash and SRAM memory. When disabled, the Memory Read Back command will return an error.

Table 2-9. Memory Readout

NM1 Address	NM1 Address [31:24]	NM1 Address [23:16]
0x60101810	READOUT[15:8]	READOUT[7:0]

Table 2-10. READOUT Data Structure

Parameter	Type	Description	Possible Values	Default Value	Device Implementation
READOUT	uint16_t	Enable or disable memory readout	BL_CFG_R EADBACK_EN = 0xAABB All other values = Memory readout disabled	0xAABB	Memory readout enabled

READOUT should only be enabled in developing environments or when memory readout is specifically required.

Even when memory readout is enabled, the BSL must still be unlocked with the correct password before the Memory Readback command can be used. This provides an additional layer of security to prevent unauthorized access to the memory contents.

2.4.5 BSL Password

The PASSWORD field stores the plain text password (32-bytes) used for BSL authentication. This password is required to unlock the bootloader and access protected BSL commands.

Table 2-11. PASSWORD

Word#	NM1 Address	NM1 Address [31:24]	NM1 Address [23:16]	NM1 Address [15:8]	NM1 Address [7:0]
Word0	0x60101814	PASSWORD[31:24]	PASSWORD[23:16]	PASSWORD[15:8]	PASSWORD[7:0]
Word1	0x60101818	PASSWORD[31:24]	PASSWORD[23:16]	PASSWORD[15:8]	PASSWORD[7:0]
Word2	0x6010181C	PASSWORD[61:54]	PASSWORD[53:48]	PASSWORD[47:40]	PASSWORD[39:32]
Word3	0x60101820	PASSWORD[95:88]	PASSWORD[87:80]	PASSWORD[79:72]	PASSWORD[71:62]
Word4	0x60101824	PASSWORD[127:120]	PASSWORD[119:112]	PASSWORD[111:104]	PASSWORD[103:96]
Word5	0x60101828	PASSWORD[155:148]	PASSWORD[147:140]	PASSWORD[139:132]	PASSWORD[131:124]
Word6	0x6010182C	PASSWORD[187:180]	PASSWORD[179:172]	PASSWORD[171:164]	PASSWORD[163:156]
Word7	0x60101830	PASSWORD[219:212]	PASSWORD[211:204]	PASSWORD[203:196]	PASSWORD[195:188]
Word8	0x60101834	PASSWORD[255:248]	PASSWORD[247:240]	PASSWORD[239:232]	PASSWORD[227:220]

Table 2-12. PASSWORD Data Structure

Parameter	Type	Description	Default Value
PASSWORD	uint32_t [8]	Bootloader 32-byte password	{0xFFFFFFFF, 0xFFFFFFFF, 0xFFFFFFFF, 0xFFFFFFFF, 0xFFFFFFFF, 0xFFFFFFFF, 0xFFFFFFFF, 0xFFFFFFFF}

Usage

The BSL password is used to protect access to critical BSL commands that can modify the device memory or read sensitive information. When the BSL is invoked, the device starts in a locked state. To unlock the BSL and access protected commands, the host must send the [Unlock Bootloader](#) command (CMD_UNLOCK_BSL, 0x21) with the correct password.

The password authentication process works as follows:

1. The host sends the Unlock Bootloader command with a 32-byte password.
2. The BSL checks if the password has the correct length (32-bytes)
3. The BSL compares the provided password with the stored password in the BSL configuration.
4. If the passwords match, the BSL is unlocked and protected commands become available.
5. If the hashes do not match, the BSL remains locked and returns a BSL_PASSWORD_ERROR.

The BSL includes several security features to protect against password attacks:

1. **Sleep Delay:** If an incorrect password is sent, the device enters sleep mode for 2 seconds and does not accept any commands during this period. This makes brute force attacks more time-consuming.
2. **Security Alert:** If an incorrect password is sent 3 times, a security alert action is taken based on the SECURITY_ALERT_LEVEL configuration. This can include:
 - a. Factory Reset: Erases all flash memory
 - b. Disable Bootloader: Permanently disable the BSL
 - c. Do Nothing: No action is taken
3. **Password Backup:** Before performing a factory reset, the BSL backs up the password to SRAM. This allows the BSL to be unlocked after a factory reset, even if the password field in NONMAIN flash is erased.

Changing the BSL Password

To change the BSL password:

1. Using BSL Commands

- a. Unlock the BSL with the current password.
- b. Update the PASSWORD field in the BSL configuration with the password.
- c. Calculate the new CRC for the BSL configuration.
- d. Program the updated BSL configuration to NONMAIN flash using the Program Data command.

Note

If you forget the BSL password, you can perform a DSSM factory reset to restore the default password. However, this erases all MAIN and NONMAIN flash memory. Alternatively, if the NONMAIN flash area is not protected, you can use CCS to re-program the BSL configuration with a new password.

2.4.6 Application Revision Pointer

The APP_REV_POINTER field contains a pointer to the application version information stored in MAIN flash memory. This allows the BSL to retrieve and report the application version when requested by the host.

Note

This value is maintained by the user. The user must allocate a section in the application linker file and update the same address in the NM1 address space for APP_REV_POINTER.

Table 2-13. APP_REV_POINTER

NM1 Address	NM1 Address [31:24]	NM1 Address [23:16]	NM1 Address [15:8]	NM1 Address [7:0]
0x60101838	APP_REV_POINTER[31:24]	APP_REV_POINTER[23:16]	APP_REV_POINTER[31:24]	APP_REV_POINTER[7:0]

Table 2-14. APP_REV_POINTER Data Structure

Parameter	Type	Description	Possible Values	Default Value
APP_REV_POINTER	uint_32t *	Pointer to the application version information stored in MAIN flash memory.	<ol style="list-style-type: none"> 1. Valid MAIN flash address 2. All other values: address is not accessed 	0xFFFFFFFF Indicates no application version is available

Usage:

The APP_REV_POINTER is used by the BSL to locate and retrieve the application version information when the Get Device Info command (CMD_GET_IDENTITY, 0x19) is executed. This allows the host to query the version of the application currently installed on the device without having to load and execute the application.

When the [Get Device Info command](#) is executed, the BSL performs the following checks:

1. Verifies that the APP_REV_POINTER contains a valid flash address
2. Checks if the address is not blank (not 0xFFFFFFFF)
3. Verifies the address is 64-bit aligned
4. If all checks pass, reads an 8-byte (64-bit) value from the specified address as the application version

If any of these checks fail, the BSL returns 0 as the application version.

Implementation Requirements:

The APP_REV_POINTER field is maintained by the customer and requires the following implementation steps:

1. **Allocate a Section in Application Linker File:** The customer must allocate a dedicated section in the application linker file to store the application version information. This section should be 64-bit aligned and located in MAIN flash memory.

2. **Define the Application Version:** The application version should be defined as a 64-bit (8-byte) value in the application code. This can be a structured value containing major, minor, and patch version numbers, or any other format that fits within 64 bits.
3. **Place the Version in the Allocated Section:** The application version value should be placed in the allocated section during the application build process.
4. **Update the APP_REV_POINTER:** The address of the allocated section must be stored in the APP_REV_POINTER field in the BSL configuration. This can be done using the methods described in [Section 2.5](#).

Note

The APP_REV_POINTER is an optional feature. If not used, it should be left at its default value of 0xFFFFFFFF, which indicates that no application version information is available.

2.4.7 Security Alert Level

The SECURITY_ALERT_LEVEL field defines the action to take when a security violation is detected, such as multiple failed password attempts.

Table 2-15. SECURITY_ALERT_LEVEL

NM1 Address	NM1 Address [15:8]	NM1 Address [7:0]
0x6010183C	SECURITY_ALERT_LEVEL[15:8]	SECURITY_ALERT_LEVEL[7:0]

Table 2-16. SECURITY_ALERT_LEVEL Data Structure

Parameter	Type	Description	Valid Values	Default Value
SECURITY_ALERT_LEVEL	uint16_t	Security alert configuration	BL_CFG_SECURITY_FACTORY_RESET = 0xAABB BL_CFG_SECURITY_DISABLE_BSL = 0xCCDD All other values = ignore issues	0xFFFF

Valid Values:

1. BL_CFG_SECURITY_FACTORY_RESET (0xAABB): Perform a factory reset when a security violation occurs
2. BL_CFG_SECURITY_DISABLE_BSL (0xCCDD): Disable the bootloader when a security violation occurs
3. All other values: Take no action when a security violation occurs

Note

The SECURITY_ALERT_LEVEL is checked only after 3 consecutive incorrect password attempts. For the first and second incorrect attempts, the device enters sleep mode for 2 seconds regardless of this configuration.

2.4.8 UART Baud Rate

The UART_BAUD_RATE field specifies the default baud rate used for UART communication in the BSL. This determines the communication speed when using the UART interface for BSL operations.

Table 2-17. UART_BAUD_RATE

NM1 Address	NM1 Address [31:24]	NM1 Address [23:16]
0x6010183C	UART_BAUD_RATE[15:8]	UART_BAUD_RATE[7:0]

Table 2-18. UART_BAUD_RATE Data Structure

Parameter	Type	Description	Valid Values	Default Value
UART_BAUD_RATE	uint16_t	UART Baud rate for ROM BSL	See Table 2-19	0x2 (9600bps)

Table 2-19. UART_BAUD_RATE Valid Values

Macro	Value	Implementation
BL_CFG_UART_BAUDRATE_4800	0x1	4800bps
BL_CFG_UART_BAUDRATE_9600	0x2	9600bps
BL_CFG_UART_BAUDRATE_19200	0x3	19200bps
BL_CFG_UART_BAUDRATE_38400	0x4	38400bps
BL_CFG_UART_BAUDRATE_57600	0x5	57600bps
BL_CFG_UART_BAUDRATE_115200	0x6	115200bps
BL_CFG_UART_BAUDRATE_1000000	0x7	1000000bps
BL_CFG_UART_BAUDRATE_2000000	0x8	2000000bps
BL_CFG_UART_BAUDRATE_3000000	0x9	3000000bps
BL_CFG_UART_BAUDRATE_4000000	0x10	4000000bps
All other values		9600bps

Changing the Baud Rate

There are two ways to change the UART baud rate:

1. Permanent Change: Modify the UART_BAUD_RATE field in the BSL configuration using the methods described in [Section 2.5](#). This changes the default baud rate used whenever the BSL is invoked.
2. Runtime Change: Use the [Change Baud Rate](#) command (CMD_CHANGE_BAUD_RATE, 0x52) during a BSL session to temporarily change the baud rate. This change is effective only for the current BSL session and reverts to the default value when the device is reset.

Note

When using the UART interface for BSL communication, both the host and the device must be configured to use the same baud rate. If the baud rate is changed using the Change Baud Rate command, the host must also change the baud rate to match.

2.4.9 I2C Target Address

The I2C_SLAVE_ADDR field specifies the target address used by the BSL when operating in I2C mode. External devices must use this address to communicate with the BSL over the I2C interface.

Table 2-20. I2C_SLAVE_ADDR

NM1 Address	NM1 Address [15:8]	NM1 Address [7:0]
0x60101840	I2C_SLAVE_ADDR[15:8]	I2C_SLAVE_ADDR[7:0]

Table 2-21. I2C_SLAVE_ADDR Data Structure

Parameter	Type	Description	Valid Values	Default Value
I2C_SLAVE_ADDR	uint16_t	I2C target address used by the ROM BSL I2C	Any 7-bit value	0x48

The default I2C target address for this device is 0x48.

The I2C_SLAVE_ADDR field sets the target address that the BSL uses when communicating over the I2C interface. When the BSL is invoked and the I2C interface is selected, the BSL configures the I2C peripheral to respond to this target address.

2.4.10 Configuration CRC

The CRC field contains a 32-bit Cyclic Redundancy Check value calculated over the entire BSL configuration structure (excluding the CRC field). This value is used to verify the integrity of the configuration data.

Table 2-22. CRC

NM1 Address	NM1 Address [31:24]	NM1 Address [23:16]	NM1 Address [15:8]	NM1 Address [7:0]
0x60101850	CRC[31:24]	CRC[23:16]	CRC[15:8]	CRC[7:0]

Table 2-23. CRC Data Structure

Parameter	Type	Description	Default Value
CRC	uint32_t	CRC of the BSL_CONFIG structure	0x5A9EA486

Default Value: 0x5A9EA486 (calculated based on default configuration values)

Valid Values: Calculated value based on the contents of the BSL configuration

The CRC field serves several important purposes:

1. Data Integrity Verification: Verifies that the BSL configuration data has not been corrupted or accidentally modified.
2. Validation of Configuration: Confirms that the BSL configuration structure is valid and complete.
3. Protection Against Errors: Helps prevent the BSL from using incorrect configuration values that can lead to unexpected behavior.

The CRC must be recalculated whenever any field in the BSL configuration is modified. This includes:

1. Initial Configuration: When the BSL configuration is first created or programmed.
2. Configuration Updates: When any field in the configuration is changed.
3. Factory Reset: After a factory reset, a new CRC is calculated for the default configuration.

An incorrect CRC in the BSL configuration results in permanent lockout due to causing a catastrophic error that is unrecoverable.

Note

When using tools like CCS to modify the BSL configuration, the CRC is typically calculated and updated automatically. However, when manually modifying the configuration using BSL commands or other methods, you must confirm that the CRC is correctly recalculated to avoid permanently damaging the device.

2.5 Changing BSL Configuration

The BSL configuration stored in NONMAIN Flash memory can be modified using several methods. This section describes the available approaches for updating BSL configuration parameters.

2.5.1 Using BSL Commands

Prerequisites:

Factory Reset must be enabled in BCR configuration (either "Enabled" or "Enabled with Password")

Procedure:

1. Invoke the bootloader using one of the supported invocation methods (GPIO, Application request, or DSSM)
2. Establish connection using the Connection command (CMD_CONNECTION, 0x12)
3. Unlock the BSL using the Unlock Bootloader command (CMD_UNLOCK_BSL, 0x21) with the current password
4. Execute Factory Reset command (CMD_FACTORY_RESET, 0x30) to erase the NONMAIN flash configuration
 - a. This erases both MAIN flash (application memory) and NONMAIN flash (configuration memory)
 - b. Provide the factory with a reset password if BCR configuration requires it (default: all 0xFF)
 - c. After factory reset, the BSL password reverts to default (hash of all 0xFF)
5. Prepare the new BSL configuration structure and calculate CRC32 for the BSL configuration:
 - a. Calculate CRC32-ISO3309 over the entire configuration structure (excluding the CRC field itself)
 - b. Use bit-reversed configuration with initial seed 0xFFFFFFFF

- c. Configuration structure size: 76 bytes (from 0x60100C00 to 0x60100C4B)
 - d. Store the calculated CRC32 value in the CRC field (0x60100C4C)
6. Program the new BSL configuration to NONMAIN flash using the Program Data command (CMD_PROGRAM_DATA, 0x20):
 - a. Start Address: 0x60100C00
 - b. Data: Complete BSL configuration structure (80 bytes total, including CRC)
 - c. Confirm the data is 16-byte aligned as required by the Program Data command
 7. Reset the device to apply the new configuration

Note

- The CRC field must be recalculated whenever any configuration field is modified
 - An incorrect CRC results in catastrophic error and permanent device lockout
 - If Factory Reset is not enabled in BCR configuration, NONMAIN flash programming fails
 - Confirm the entire configuration structure is programmed, not just individual fields
-

2.5.2 Using Debug Interface

If the NONMAIN flash area is not write-protected, the BSL configuration can be directly programmed using a debug probe:

1. Connect a debug probe (XDS110, etc.) to the device
2. Use Code Composer Studio Flash Loader or similar tool
3. Load the BSL configuration binary file
4. Program to NONMAIN flash starting at address 0x60100800

3 Bootloader Protocol

3.1 Packet Format

The BSL data packet has a layered structure. The BSL core command contains the actual command data to be processed by the BSL. In addition to the standard BSL commands, there can be wrapper data before and after each core command known as the peripheral interface code (PI Code). This wrapper data is information that is specific to the peripheral and protocol being used, and it contains information that allows for correct transmission of the BSL core command. Taken together, the wrapper and core command constitute a BSL data packet

PI Code	BSL Core Data	PI Code
---------	---------------	---------

3.2 BSL Protocol

The data packets of the UART, I2C, and MCAN BSL protocol have the following structure.

- Header byte indicates the protocol used and the packet type (command or response packet).
 - 0x80 = Command packet
 - 0x08 = Response packet
- Length field contains the size of the BSL Core Data in bytes.
- BSL core data, contains the Command / Response ID and Address, data as needed by the command
- CRC32 field contains the CRC calculated for the data in BSL core data

PI Code		BSL Core Data	PI Code
Header (1 byte)	Length (2 byte)	BSL Core Command/Response	CRC32 (4 bytes)

Based on the Core data field, the data packet is classified as either a command packet or response packet.

- 0x80 = Command packet
- 0x08 = Response packet

Command packet is the first packet which is transmitted to the BSL. The second packet is the Response packet which is received from the BSL. Response packet contains two components BSL acknowledgment and BSL Core response. In these two, Acknowledgment is received from BSL for every command packet sent. But the BSL core response is not received for every command.




Figure 3-1. BSL Protocol

3.2.1 BSL Acknowledgment

The peripheral interface section of the BSL software parses the wrapper section of the BSL data packet. If there are errors with the data transmission, an error message is sent immediately. An ACK is sent after all data has been successfully received and does not mean that the command has been correctly executed (or even that the command was valid) but, rather, that the data packet was formatted correctly and passed on to the BSL core software for interpretation.

The BSL protocol dictates that every BSL data packet sent is responded to with a single byte acknowledgment in addition to any BSL data packets that are sent. Table 3-1 lists the acknowledgment responses from the BSL. If an acknowledgment byte other than ACK is sent, the BSL does not send any BSL data packets. The host programmer must check the acknowledgment error and retry transmission.

Table 3-1. BSL Acknowledgement Responses

Data	Error Code
0x00	BSL_ACK (Packet received successfully)

Table 3-1. BSL Acknowledgement Responses (continued)

Data	Error Code
0x51	BSL_ERROR_HEADER_INCORRECT
0x52	BSL_ERROR_CHECKSUM_INCORRECT
0x53	BSL_ERROR_PACKET_SIZE_ZERO
0x54	BSL_ERROR_PACKET_SIZE_TOO_BIG
0x55	BSL_ERROR_UNKNOWN_ERROR
0x56	BSL_ERROR_UNKNOWN_BAUD_RATE
0x57	BSL_ERROR_AUTH_FAILED

3.2.2 Peripheral Configuration

3.2.2.1 UART

UART is enabled with following configuration:

- UC4 is used
- Baud rate 9600 bps by default (can be updated by Change Baud Rate command)
- Data width: 8 bit
- Flow control: None
- Stop bits: 1
- Parity: None
- Pins used for RXD and TXD are taken from the BSL configuration

3.2.2.2 I2C

The I2C interface in the BSL can act as the I2C target. The host acts as a controller and drives the communication.

- UC2 is used
- The I2C target address is 0x48, by default (can be configured in BSL Configuration)
- External pullup is needed for SCL and SDA lines
- Pins used for SDA and SCL are taken from the BSL configuration

3.2.2.3 MCAN

MCAN is enabled with following configuration:

- MCAN0 is used
- Clock source is CANCLK
 - Requires PLL to be configured to 80MHz or a 20 MHz XTAL connected
- Baud rate is 1 Mbps (nominal and data)
- Pins used for RX and TX are taken from the BSL configuration

3.2.2.4 CRC

CRC for the data must be calculated with:

- CRC32-ISO3309 polynomial
- Bit reversed configuration
- Initial seed - 0xFFFFFFFF

3.3 Bootloader Core Commands

Table 3-2. BSL Commands

BSL Command	Protected	Command Code (byte)	Start Address (bytes)	Data (bytes)	BSL Core Response
Connection	No	0x12	-	-	No
Unlock Bootloader	No	0x21	-	D1...D32 (Password)	Yes
Flash Range Erase	Yes	0x23	A1...A4 (Start Address)	A1...A4 (End Address)	Yes
Mass Erase	Yes	0x15	-	-	Yes
Program Data	Yes	0x20	A1...A4	D1...Dn	Yes
Program Data Fast	Yes	0x24	A1...A4	D1...Dn	No
Memory Readback	Yes	0x29	A1...A4	L1...L4	Yes

Table 3-2. BSL Commands (continued)

BSL Command	Protected	Command Code (byte)	Start Address (bytes)	Data (bytes)	BSL Core Response
Factory Reset	Yes	0x30	-	D1...D16 (Password)	Yes
Get Device Info	No	0x19	-	-	Yes
Standalone Verification	Yes	0x26	A1...A4	L1...L4	Yes
Start Application	No	0x40	-	-	No
Change Baudrate	No	0x52	-	D1 (Baud Rate ID)	No

Abbreviations:

A1...A4: Address bytes, where A1 is the least significant byte

D1..Dn: Data bytes, where 'n' is limited by the BSL maximum buffer size

L1...L4: Data Length bytes, where L1 is the least significant byte

3.3.1 Connection

Structure

Header	Length		CMD	CRC32			
0x80	0x01	0x00	0x12	C1	C2	C3	C4

Description

Connection command is the first command used to establish the connection between the Host and the Target through a specific interface (UART, I2C, or MCAN).

Protected

No

Command Returns

Only [BSL Acknowledgment](#)

Example

Host: 80 01 00 12 3A 61 44 DE

BSL: 00

3.3.2 Get Device Info

Structure

Header	Length		CMD	CRC32			
0x80	0x01	0x00	0x19	C1	C2	C3	C4

Description

The command is used to get the version information and buffer size available for data transaction.

Protected

No

Command Returns

BSL Acknowledgment and BSL core response with device information. See [Device info](#) for more details.

Example

Host: 80 01 00 19 B2 B8 96 49

BSL:00 08 19 00 31 00 01 00 01 00 00 00 00 01 00 C0 06 60 01 00 20 01 00 00 00 01 00 00 00 49 61 57 8C

Data bytes to be written in the specified address. Maximum size of the data that can be sent is limited by the Buffer size of the device. Buffer size is known from Get Device Info [command](#) .

Command Returns

BSL Acknowledgment and BSL core response with Message about the Status of the operation. See section [Section 3.4.1](#) for more details.

Example

Host: 80 0D 00 20 00 00 00 00 00 00 00 04 00 00 00 08 7A DC AE B8

BSL: 00 08 02 00 3B 00 38 02 94 82

3.3.5 Program Data Fast

Structure

Header	Length		CMD	Address	Data	CRC32			
0x80	L1	L2	0x24	A1...A4	D1...Dn	C1	C2	C3	C4

Description

The Program Data Fast command is identical to the Program Data command, except that this command performs a non-blocking write to speed up the programming process. The BSL will not send the BSL core message response to indicate if the programming was successful for this command.

Protected

Yes

Address

Start address of the memory region to be programmed. A1...A4, where A1 is the least significant byte of the 32 bit address.

Data

Data bytes to be written in the specified address. Maximum size of the data that can be sent is limited by the Buffer size of the device. Buffer size is known from Get Device Info [command](#) .

Command Returns

BSL Acknowledgment.

Example

Host: 80 0D 00 24 00 01 00 00 01 02 03 04 05 06 07 08 72 10 2A 18

BSL: 00

3.3.6 Readback Data

Structure

Header	Length		CMD	Address	Data	CRC32			
0x80	0x09	0x00	0x29	A1...A4	L1...L4	C1	C2	C3	C4

Description

This command is used to readout the data starting from address A1...A4.

Readout should be enabled in the BSL configuration to use this command. It is disabled by default in the BSL configuration.

Data readout is allowed for MAIN flash (application memory), NONMAIN Flash (configuration memory) and SRAM memory.

Note

SRAM memory is not fully accessible by the Host. See [SRAM memory usage](#) for more details.

Protected

Yes

Address

Start address of the memory region to be read back, A1...A4, where A1 is the least significant byte of the 32 bit address.

Data

Size of the data to be read in bytes, L1...L4, where L1 is the least significant byte. Maximum size of the data that can be read is limited by the Buffer size of the device. Buffer size is known from [Get Device Info command](#).

Command Returns

BSL Acknowledgment and BSL core response with requested data, if the readback command is valid. See [Section 3.4.3](#) for more details.

If the readback command, had invalid address / length or if the readout was disabled, the corresponding error will be sent as the Message Response following the BSL acknowledgment.

Example

Host: 80 09 00 29 00 0C 00 00 08 00 00 00 32 9D B0 35

BSL: 00 08 09 00 30 FF FF FF FF FF FF FF F6 2B A1 73

3.3.7 Flash Range Erase

Structure

Header	Length		CMD	Address	Data	CRC32			
0x80	0x09	0x00	0x23	A1...A4 (Start)	A1...A4 (End)	C1	C2	C3	C4

Description

The flash range erase command is used to erase the specified flash memory region. Flash is erased sector wise (2 KB), erasing with smaller granularity is not possible.

When the Start and End address reside in different flash sectors, the BSL erases all the flash sectors in between the Start and End address, including sectors that contains these addresses.

This command can be used to erase only the MAIN flash memory. NONMAIN erase is not possible.

End address should never be less than Start address.

Protected

Yes

Address

Start address of the memory region to be erased. A1...A4, where A1 is the Least Significant Byte of the 32 bit address.

Data

End address of the memory region to be erased. A1...A4, where A1 is the Least Significant Byte of the 32 bit address.

Command Returns

BSL Acknowledgment and BSL core response with Message about the Status of the operation. See section [Section 3.4.1](#) for more details.

Example

Host: 80 09 00 23 00 01 00 00 FF 03 00 00 2B E6 BE D8

BSL: 00 08 02 00 3B 00 38 02 94 82

3.3.8 Mass Erase

Structure

Header	Length		CMD	CRC32			
0x80	0x01	0x00	0x15	C1	C2	C3	C4

Description

The mass erase command erases all MAIN flash memory (application memory) available in the device.

The mass erase configuration in BCR configuration memory doesn't affect this BSL command.

When a flash region is static write protected in BCR configuration memory, the region can't be erased.

Protected

Yes

Command Returns

BSL Acknowledgment and BSL core response with Message about the Status of the operation. See [Section 3.4.1](#) for more details.

Example

Host: 80 01 00 15 99 F4 20 40

BSL: 00 08 02 00 3B 00 38 02 94 82

3.3.9 Factory Reset

Structure

Header	Length		CMD	Data	CRC32			
0x80	L1	L2	0x30	D1...D16	C1	C2	C3	C4

Description

The factory reset command erases the complete MAIN flash (application) memory and NONMAIN flash (configuration) memory.

Processing this command, is impacted by the factory reset configuration in the BCR configuration memory.

Factory reset is:

- Allowed without password, if 'Enabled'
- Allowed with password, if 'Enabled with Password'
- Not allowed, if 'Disabled'

When a flash region is static write protected in BCR configuration memory, the region can't be erased .

Protected

Yes

Data

16-byte factory reset password stored in the BCR configuration memory. The default password is all 0xFF. Password is required only when Factory reset is "Enabled with Password" in BCR configuration.

Command Returns

BSL Acknowledgment and BSL core response with Message about the Status of the operation. See [Section 3.4.1](#) for more details.

CAUTION

After doing the factory reset, until the NONMAIN configuration has been restored, the system is highly vulnerable to a potential lock out situation in which it is impossible to get access to the device again.

Example

Scenario 1: Factory Reset without Password

Host: 80 01 00 30 DE 20 24 0B

BSL: 00 08 02 00 3B 00 38 02 94 82

Scenario 2: Factory Reset with Password

Host : 80 11 00 30 FF 8A 28 EA DC

BSL : 00 08 02 00 3b 00 38 02 94 82

3.3.10 Standalone Verification

Structure

Header	Length		CMD	Data	Length	CRC32			
0x80	0x09	0x00	0x26	A1...A4	L1...L4	C1	C2	C3	C4

Description

This command is used to verify the CRC of the data stored at the given memory range. This enables faster verification of the programmed data. It requires the data size to be minimum 2KB.

CRC verification is allowed for MAIN flash (application memory) and NONMAIN flash (configuration memory).

Protected

Yes

Address

Start address of the memory region to be verified, A1...A4, where A1 is the least significant byte of the 32 bit address.

Data

Size of the data to be verified in bytes, L1...L4, where L1 is the least significant byte.

2KB <= Data Size <= 512 KB.

Command Returns

BSL Acknowledgment and BSL core response with CRC value calculated for the requested memory region. Refer to [Section 3.4.5](#) for more details.

If the verification command has an invalid address or length, the corresponding error will be sent as the Message Response following the BSL acknowledgment. Refer to [Section 3.4.1](#) for more details.

Example

Host: 80 09 00 26 00 00 00 00 00 08 00 00 C0 41 0E E6

BSL: 00 08 02 00 3B 05 B7 F6 FE F2

3.3.11 Start Application

Structure

Header	Length		CMD	CRC32			
0x80	0x01	0x00	0x40	C1	C2	C3	C4

Description

The start application command issues a system reset, which causes the BSL to exit and re-run the bootcode. This will in turn start the application.

Protected

No

Command Returns

BSL Acknowledgment

Example

Host: 80 01 00 40 E2 51 21 5B

BSL: 00

3.3.12 Change Baud Rate

Structure

Header	Length		CMD	Data	CRC32			
0x80	0x02	0x00	0x52	D1	C1	C2	C3	C4

Description

The command can be used to change the baud rate of the UART interface. The new baud rate will take effect after sending out the BSL acknowledgment for this packet.

The default baud rate of the UART BSL is 9600 bps.

Note

After updating the baud rate, if a wrong BSL password is sent with the Unlock Bootloader command, the baud rate settings will be reverted to default value. Further communication occurs at the default baud rate (9600 bps).

Protected

No

Data

D1: Baud Rate ID as specified in the table.

ID	Baud Rate (bps)
0x1	4800
0x2	9600
0x3	19200
0x4	38400
0x5	57600

ID	Baud Rate (bps)
0x6	115200
0x7	1000000
0x8	2000000
0x9	3000000
0x10	4000000

Command Returns

BSL Acknowledgment

Example

Host: 80 02 00 52 03 6C 83 A2 AF

BSL: 00

3.4 Bootloader Core Response

Table 3-3. BSL Responses

BSL Response	RSP	Data
Memory read back	0x30	D1...Dn
Get Device Info	0x31	D1...D24
Standalone verification	0x32	D1...D4
Message	0x3B	MSG
Detailed Error	0x3A	D1..D3

Abbreviations:

MSG:

A byte containing a response from the BSL core describing the result of the requested action. This can either be an error code or an acknowledgment of a successful operation. In cases where the BSL is required to respond with data (for example, memory, version, CRC, or buffer size), no successful operation reply occurs, and the BSL core immediately sends the data.

D1..Dn:

Data bytes, where 'n' is limited by the BSL maximum buffer size

3.4.1 BSL Core Message

Structure

Header	Length		RSP	Data	CRC32			
0x08	0x02	0x00	0x3B	MSG	C1	C2	C3	C4

Description

For some commands, BSL sends the message response to the host, which indicates the status of the processed command. The table lists all the possible messages from the BSL.

MSG	Meaning	Possible Cause ⁽¹⁾
0x00	Operation Successful	
0x01	BSL Locked error	The BSL is not yet unlocked with Bootloader unlock password command or After BSL unlock, a timeout would have occurred in the command reception phase
0x02	BSL password error	Incorrect password has been sent to unlock bootloader.
0x03	Multiple BSL password error. Security Alert action is taken.	Incorrect password has been sent to unlock bootloader 3 times.

MSG	Meaning	Possible Cause ⁽¹⁾
0x04	Unknown Command	The command given to the BSL was not recognized as valid command
0x05	Invalid memory range	The given memory range is invalid.
0x06	Invalid command	The command given to the BSL is a known command but it is invalid at that time instant and cannot be processed.
0x07	Factory reset disabled	Factory reset is disabled in the BCR configuration
0x08	Factory reset password error	Incorrect or no password has been sent with factory reset command, when the BCR configuration has factory reset 'Enabled with password'
0x09	Read out error	Memory read out be disabled in BCR configuration
0x0A	Invalid address or length alignment	Start address or data length for the flash programming is not 8-byte aligned
0x0B	Invalid length for standalone verification	Data size sent for standalone verification is less than 2KB

(1) Possible causes listed here, are not the only reason for the status or error. It only lists the probable software reasons for the error, that can be corrected by the host.

3.4.2 Detailed Error

Structure

Header	Length		RSP	Data	CRC32			
0x08	0x02	0x00	0x3A	D1..D3	C1	C2	C3	C4

Description

D1 - Error Type

D3, D2 - Error Details

Possible Values

Error type		Error Details	
Value	Description	Value	Description
0xF0	Flash Error	0xFF	Contains FLASHCTL.STATCMD register value

3.4.3 Memory Readback

Structure

Header	Length		RSP	Data	CRC32			
0x08	0x02	0x00	0x30	D1...Dn	C1	C2	C3	C4

Description

The command returns the requested data in response to the Readback [command](#)

Data

Data D1..Dn where 'n' is limited by the BSL maximum buffer size.

3.4.4 Device Info

Structure

Header	Length		RSP	Data	CRC32			
0x08	0x19	0x00	0x31	D1...D24	C1	C2	C3	C4

Description

The command returns the version information and BSL buffer size in response to the Get Identity [Command](#)

Data

Identity Byte	Data Byte
Command Interpreter version	[D02-D01]
Build ID	[D04- D03]
Application version	[D08-D05]
Active Plug-in interface version	[D10-D09]
BSL Max buffer size	[D12-D11]
BSL Buffer Start address	[D16-D13]
BCR Configuration ID	[D20-D17]
BSL Configuration ID	[D24- D21]

Application version:

32 bit application version is taken from the address specified in BSL configuration

BSL Buffer size:

RAM data buffer size available to store the BSL data packets that are sent/received.

Example

Host: 80 01 00 19 B2 B8 96 49

BSL: 00 08 19 00 31 00 01 00 01 00 00 00 00 01 00 C0 06 60 01 00 20 01 00 00 00 01 00 00 00 49 61 57 8C

In the above given response,

Command Interpreter version - 0x0100

Build ID - 0x0100

Application version - 0x00000000

Active Plug-in interface version - 0x0001

BSL Max buffer size - 0x06C0

BSL Buffer Start address - 0x20000160

BCR Config ID - 0x00000001

BSL Config ID - 0x00000001

3.4.5 Standalone Verification

Structure

Header	Length		RSP	Data	CRC32			
0x08	0x05	0x00	0x32	D1...D4	C1	C2	C3	C4

Description

The command returns the CRC value in response to the standalone verification command

Data

32 bit CRC value calculated for the requested memory region. D1...D4, where D1 is the least significant byte of the CRC32.

3.5 Bootloader Security

3.5.1 Password Protected Commands

All the commands that can access the data in the memory directly or indirectly are password protected. The password is configurable in the BSL configuration in NONMAIN flash memory.

When an incorrect password is sent, device will sleep for next 2 seconds and does not accept any command during this period to make brute-force attacks harder. When incorrect password is sent for 3 times, security alert action is taken by the BSL.

3.5.1.1 Security Alert

A security alert can be configured to any of the following three modes, in the BSL configuration:

1. **Factory Reset**- Factory reset erases the complete MAIN and NONMAIN flash memories. The erase is done irrespective of the factory reset mode in the BCR configuration. If certain parts of the flash are static write protected, the BSL cannot erase the complete flash memory.
2. **Disable Bootloader** - Disables the bootloader in the BCR configuration and exits from BSL. No further entry to BSL is possible, unless the BCR NONMAIN configuration is updated to enable the bootloader. The BSL is not disabled if static write protection is enabled for NONMAIN.
3. **Do Nothing** - Does not take any action.

Note

For the factory reset security alert configuration, if NONMAIN is erased, the bootloader password returns to the default. To prevent this, NONMAIN can be write protected. If NONMAIN is left in the erased state, the device is locked and it is not possible to gain access to the device again.

3.5.2 BSL Entry

Entry to BSL is allowed only through the Bootcode (BCR).

The BSL can be disabled in BCR configuration.

4 Sample Program Flow with Bootloader

This section explains the typical sequence followed by the BSL host for loading the image through the AM13E230x BSL. This sample sequence erases the flash memory and programs new firmware in it.

- Bootloader shall be started through one of the following methods:
 - Pin based invocation (GPIO)
 - Application request
 - DSSM command
- Once the BSL is invoked, send the connection command to establish connection with the BSL through the desired interface.
- *Optional:* If UART interface is used, the baud rate can be changed to a higher value to speed up further communication.
- To erase the flash memory completely use the Mass Erase command. If there is a need to update NONMAIN flash, use the Factory Reset command. If the NONMAIN flash is erased and left unprogrammed the device is locked.
- Program the firmware image
- *Optional:* Complete the CRC verification of the programmed memory region to check the correctness of data programmed.
- Application can be started with the Start Application command.




Figure 4-1. BSL Host Sequence

5 Revision History

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

DATE	REVISION	NOTES
March 2026	*	Initial Release

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you fully indemnify TI and its representatives against any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](#), [TI's General Quality Guidelines](#), or other applicable terms available either on [ti.com](#) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products. Unless TI explicitly designates a product as custom or customer-specified, TI products are standard, catalog, general purpose devices.

TI objects to and rejects any additional or different terms you may propose.

Copyright © 2026, Texas Instruments Incorporated

Last updated 10/2025