## Technical Article How to Make Precision Measurements on a Nanopower Budget, Part 1: DC Gain in Nanopower Op Amps



Gen Vansteeg

Heightened accuracy and speed in an operational amplifier (op amp) has a direct relationship with the magnitude of its power consumption. Decreasing the current consumption decreases the gain bandwidth; conversely, decreasing the offset voltage increases the current consumption.

Many such interactions between op amp electrical characteristics influence one another. With the increasing need for low power consumption in applications like wireless sensing nodes, the Internet of Things (IoT) and building automation, understanding these trade-offs has become vital to ensure optimal end-equipment performance with the lowest possible power consumption. In the first installment of this two-part blog post series, I'll describe some of the power-to-performance trade-offs of DC gain in precision nanopower op amps.

## DC Gain

You probably remember from school the classic inverting (Figure 1) and noninverting (Figure 2) gain configurations of op amps.





1



These configurations resulted in inverting and noninverting op amp closed-loop gain equations, Equations 1 and 2, respectively:

$$A_{CL} = -\frac{R_F}{R_2} = -\frac{V_{OUT}}{V_{IN}}$$
(1)  $A_{CL} = 1 + \frac{R_F}{R_2} = \frac{V_{OUT}}{V_{IN}}$ (2)

where  $A_{CL}$  is the closed-loop gain,  $R_F$  is the value of the feedback resistor and  $R_2$  is the value of the resistor from the negative input terminal to signal (inverting) or ground (noninverting).

These equations are a reminder that DC gain is based on resistor ratio, not resistor value. Additionally, the "power" law and Ohm's law show the relationships between resistor value and power dissipation (Equation 3):

$$P = VI$$
 (3)

where P is the power consumed by the resistor, V is the voltage drop across the resistor and I is the current through the resistor.

For nanopower gain and voltage divider configurations, Equation 3 tells you that, in order to minimize power dissipation, you need to minimize the current consumption by the resistor. Equation 4 helps you understand the mechanism to do that:

$$V = IR$$
 (4)

where R is the resistor value.

Using these equations, you can see that you must choose large resistor values that provide both the gain you need while minimizing power dissipation (and therefore power consumption). If you don't minimize current through the feedback path, you'll lose the benefit of using nanopower op amps.

Once you've determined what resistor values will meet your gain and power-consumption needs, you'll need to consider some of the other op amp electrical characteristics that will affect the accuracy of signal conditioning. Summing several small systemic errors inherent in nonideal op amps will give you the total offset voltage. The electrical characteristic,  $V_{OS}$ , is defined as a finite offset-voltage number between the op amp inputs, and describes these errors at a defined bias point. Please note that it does not describe these errors across all operating conditions. To do that, you must consider the gain error, bias current, voltage noise, common-mode rejection ratio (CMRR), power-supply rejection ratio (PSRR) and drift. Covering all of these parameters is beyond the scope of this post, but let's look at  $V_{OS}$  and drift – and their influence in nanopower applications – in a bit more detail.

Real-world op amps exhibit  $V_{OS}$  across their input terminals, which can sometimes be a problem in low-frequency (close to DC) precision signal-conditioning applications. In voltage gain configurations, the offset voltage will gain up along with the signal being conditioned, introducing measurement errors. In addition, the magnitude of  $V_{OS}$  can change over both time and temperature (drift). Therefore, in low-frequency applications requiring fairly high-resolution measurements, it's important to select a precise ( $V_{OS} \le 1$ mV) op amp with the lowest possible drift.

Equation 5 calculates the worst-case  $V_{OS}$  over temperature:

$$|V_{OS_{maxtemp}}| = |V_{OS(25^{\circ}C)}| + |TCV_{OS_{max}}| \times Application Temp Range$$
 (5)

Now that I've covered theory, including choosing large resistor values to create gain ratios and op amp accuracy for low-frequency applications, I'll go over a practical example using two-lead electrochemical cells. For two-lead electrochemical cells which often emit very small signals of low frequency, and are used in diverse portable sensing applications like gas detection and blood glucose monitoring, choose a low-frequency (<10kHz) nanopower op amp.

2



Using oxygen sensing (see Figure 3) as the specific application example, assume that the maximum concentration of the sensor outputs 10mV (converted from current to voltage by a manufacturer-specified load resistor,  $R_L$ ) and the full-scale output of the op amp is 1V. Using Equation 2, you can see that  $A_{CL}$  needs to be 100, or  $R_F$  needs to be 100 times larger than  $R_2$ . Choosing values of 100M $\Omega$  and 1M $\Omega$ , respectively, gives you a gain of 101, and these resistor values are large enough to limit current and minimize power consumption.



To minimize offset error, the LPV821 zero-drift nanopower op amp is a good choice. Using Equation 5 and assuming an operating temperature range from 0°C to 100°C, the worst-case offset error introduced by this device will be:

$$V_{OS_{temp_LPVe21}} = |10\mu V| + |0.08^{\mu V}/_{\circ C}| \times 100^{\circ C} = |18\mu V|$$

Another good choice is the LPV811 precision nanopower op amp. Using its data sheet to gather the necessary values plugged into Equation 5 gives you:

$$V_{OS_{temp\_LPVell}} = |370\mu V| + |1^{\mu V}/_{\circ C}| \times 100^{\circ C} = |470\mu V|$$

(Note that the LPV811 data sheet does not specify a maximum offset voltage drift limit, so I am using the typical value here.)

If you were to use a general-purpose nanopower op amp like the TLV8541 instead, those values would result in:

$$V_{OS_{temp_TLVes_{41}}} = |3.1mV| + |0.8^{\mu V}/_{\circ C}| \times 100^{\circ C} = |3.18mV|$$

(The TLV8541 data sheet also does not specify a maximum offset voltage drift limit, so I again used the typical value here.)

As you can see, the LPV821 op amp is the best choice for this application. With 650nA of current consumption, the LPV821 can sense changes in the output of the oxygen sensor down to  $18\mu$ V or lower, and introduces a maximum offset gain error of only 2.3mV. When you need both extreme precision and nanopower consumption, a zero-drift nanopower op amp will provide the best possible performance.

Thanks for reading this first installment of the "How to make precision measurements on a nanopower budget" series. In the next installment, I'll discuss how ultra-precise nanopower op amps can help in current-sensing applications. If you have any questions about precision measurements, log in and leave a comment, or visit the TI E2E™ Community Precision Amplifiers forum.



## **Additional Resources**

- Download the LPV821, LPV811 and TLV8541 data sheets.
- Read about designing on a nanopower budget in these TI TechNotes:
  - "Current Sensing in No-Neutral Light Switches."
  - "Advantages of Using Nanopower Zero-Drift Amplifiers for Battery Voltage and Current Monitoring in Portable Applications."
  - "Simplifying Measurements in Power-Conscious Industrial Analytics Systems with Nanopower Op Amps."
- Check out all of TI's amplifier devices.

## IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2023, Texas Instruments Incorporated