



THIS DRAWING IS INTENDED TO HELP IN THE ASSEMBLY OF THE DESIGN.

- 1. REFER TO ODB++ FILE FOR SPECIFIC COMPONENT LOCATION INFORMATION.
- 2. USE WATER SOLUBLE FLUX DURING BOARD ASSEMBLY.
RoHS COMPLIANT AND LEAD FREE.
- 3. MOUNT THE RF FENCE ON THE TOP OF THE PCB AFTER BOARD ASSEMBLY.
SOLDER THE FENCE DOWN TO THE BOARD AROUND THE EDGES. NO GAPS.
PLACE THE RF COVER ON THE FENCE.

REVISIONS				
ZONE	LTR	DESCRIPTION		DATE

SEE NOTE 3
4 PLC'S

TOP VIEW

BOTTOM VIEW

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES +/- .XX +/- .01 +/- .XXX +/- .005 +/-	CONTRACT NO.		TEXAS INSTRUMENTS INC.					
	APPROVALS		DATE		ASSEMBLY DRAWING DAC3XJ8X EVM			
	DRAWN JV SMITH		12-18-12					
	ENGR M GUIBORD		12-18-12					
MATERIAL								
SEE NOTE 5								
FINISH					SIZE	CODE IDENT NO.	DRAWING NO.	REV.
SEE NOTES 7, 8, 9					B			D
DO NOT SCALE DRAWING					SCALE	NONE		SHEET 1 OF 1